

Idea and **Opera**®

Aluminium coated cars

INSTALLATION AND COMMISSIONING INSTRUCTIONS



sample images



LIFTINGITALIA
AREALIFT®

HOMELIFTS & PLATFORM LIFTS MADE IN ITALY



PURPOSE OF THE MANUAL	3
PERSONAL SECURITY AND RISK RECOGNITION	3
MANUAL READING GUIDE	4
LIABILITY AND WARRANTY CONDITIONS	4
1. GENERAL DISPOSITIONS AND INSTALLATION SITE MANAGEMENT	5
1.1. GENERAL DISPOSITIONS	5
1.2. INSTALLATION SITE - COMPONENTS POSITIONING	6
2. PRODUCT DESCRIPTION	7
2.1. GENERAL DESCRIPTION AND TERMINOLOGY	7
2.2. COMPONENTS IDENTIFICATION	8
3. TOOLS AND MATERIALS REQUIRED FOR INSTALLATION	9
4. BOX CONTENT - SCREWS KIT	10
5. BASEMENT ASSEMBLY	12
6. CAR ASSEMBLY	13
6.1. UPRIGHT PREPARATION	13
6.2. UPRIGHTS FIXING TO THE BASEMENT	15
6.3. WALL FIXING	16
6.4. CEILING - MOUNTING	17
6.5. ACCESS TO THE SHAFT IN THE PRESENCE OF SUSPENDED CEILING	24
6.6. HANDRAIL - INSTALLATION	25
7. HANDRAIL - INSTALLATION	26

2.1	Insertion p. 27 (Fermator car door drive)	26.06.2023
2.0	General update	28.04.2021
1.3	Update page 20	25.06.2018
1.2	Update page 9	01.12.2015
1.1	Update pages 10, 12, 17	02.02.2015
1	Update images, edit pages 4, 5, 8	27.02.2014
Rev.	Descrizione	Data



PURPOSE OF THE MANUAL

The purpose of this manual is to provide correct information on the installation of the product, in order to contribute to personal safety and to the proper functioning of the system. Keep the manual for the entire life of the product. In the event of a change of ownership, the manual must be provided to the new user as an integral part of the product.

NOTICE



READ THIS MANUAL CAREFULLY before installing and using the product. This product must be installed and put into operation according to the provisions and regulations in force. Improper installation or improper use of the product can cause damage to people and property, as well as cause the warranty to lapse.

FOLLOW THE SUGGESTIONS AND RECOMMENDATIONS TO OPERATE IN SAFETY. Any unauthorized modification can compromise the safety of the system, as well as the correct operation and the life of the machine. If you have any doubts regarding the correct understanding of the information and contents contained in this manual, contact LIFTING ITALIA S.r.l. immediately.

QUALIFIED PERSONNEL: The product covered by this documentation can only be installed by qualified personnel, in compliance with the attached technical documentation, above all in compliance with the safety warnings and the precautions contained therein.

Keep the technical and safety documentation near the system.



PERSONAL SECURITY AND RISK RECOGNITION

This manual contains safety rules that must be observed to safeguard personal safety and to prevent damage to the property. The indications to be followed to guarantee personal safety are highlighted by a triangle symbol while those to avoid material damage are not preceded by the triangle. The hazard warnings are shown as follows and indicate the different levels of risk in descending order.

RISK SYMBOLOGY AND PHRASES

RISK CLASSIFICATION AND RELATIVE GRAVITY OF DAMAGE		
DANGER	The symbol indicates that the failure to comply with appropriate safety measures causes death or serious physical injury.	RISK LEVEL
WARNING	The symbol indicates that the failure to observe the corresponding safety measures can cause death or serious personal injury.	
CAUTION	The symbol indicates that failure to observe the relevant safety measures can cause minor or moderate personal injury or damage to the device.	
NOTICE	It is not a symbol of security. It indicates that the failure to comply with relevant safety measures can result in property damage.	
INFORMATION	It is not a symbol of security. It indicates important information.	

If there are multiple levels of risk, the danger warning always indicates the highest one. If a warning is drawn with a triangle to warn of the risk of injury to persons, the risk of possible property damage may also be caused at the same time.

NOTE: During installation / maintenance of the platform, the safety functions are temporarily suspended. Therefore all necessary precautions must be taken to avoid personal injury and / or damage to the product.



MANUAL READING GUIDE

WARNING SIGN

	GENERAL DANGER		ELECTRICITY DANGER		DANGER FLAMMABLE MATERIAL
	DANGER OF FALL BY A LEVEL		DANGER SUSPENDED LOADS		DANGER OF CRUSHING

PROHIBITION SIGN

	GENERIC PROHIBITION		FORBIDDEN TO STEP ON		PROHIBITED TO WALK ON OR STOP IN THIS AREA
--	---------------------	--	----------------------	--	--

MANDATORY SIGN

	OBLIGATORY TO WEAR THE PROTECTION HELMET		OBLIGATORY TO WEAR SAFETY SHOES		OBLIGATORY WEAR THE PROTECTIVE GLOVES
	OBLIGATORY TO WEAR EYE PROTECTION		OBLIGATION TO WEAR THE AUDIO PROTECTION		OBLIGATORY TO WEAR THE MASK
	OBLIGATORY TO WEAR PROTECTIVE CLOTHES		OBLIGATORY TO KEEP CLOSED		OBLIGATORY TO CHECK THE PROTECTIONS

EMERGENCY AND FIRST AID SIGNS

INDICATION SYMBOLS

	FIRST AID		NOTA BENE		KEEP DRY		OBLIGATORY TO CHECK THE PROTECTIONS
--	-----------	--	-----------	--	----------	--	-------------------------------------



LIABILITY AND WARRANTY CONDITIONS:

RESPONSIBILITY OF THE INSTALLER

The elevator / platform is produced and intended to be installed as described in the attached project drawing and in this manual; any divergence from the prescribed procedure may affect the operation and safety of the system and cause the immediate cancellation of the warranty.

Any modification or variation made to the project and the assembly Instructions must be documented in detail and referred to LIFTING ITALIA S.r.l., in order to allow the company an adequate assessment. Under no circumstances can a modified system be activated without the express authorization of LIFTING ITALIA S.r.l.

Installers are responsible for ensuring compliance with safety procedures at work and any health and safety regulations in force in the country and on the site where the assembly is carried out.

The elevator / platform must only be used in the way envisaged by the system and illustrated in the relative manuals (transportation of people and / or things, maximum loads, cycles of use, etc.). LIFTING ITALIA S.r.l. assumes no responsibility for damage to persons and property caused by improper use of the system.

NOTE: Pictures and images on this manual are for illustration purposes only.



1. GENERAL DISPOSITIONS AND INSTALLATION SITE MANAGEMENT

1.1. GENERAL DISPOSITIONS

IMPORTANT!

 For more information on safety, liability and warranty conditions, receipt and storage of material on site, packaging, waste disposal, cleaning and storage of the product; refer to the "**SAFETY INSTRUCTIONS AND SITE MANAGEMENT**" manual.

NOTICE


PRELIMINARY CHECKS: Once the packaging has been opened, check that the product is intact and has not been damaged during transport. Should any anomalies or damage be found, please dispatch them in writing on the transport document to the transport company, giving written notice to LIFTINGITALIA S.r.l.

NOTE: In this manual, we will talk about "SHAFT" meaning for it the base slab, the slab of landing and the vertical wall that connects its slabs.

CAUTION


SAFETY AND SITE MANAGEMENT - OVERALL DISPOSITIONS:

1. Always secure tools and any objects against falling;
2. Pay the utmost attention to all the steps described in this;
3. While assembling the parts making up the system or after installation, be careful of any sharp burrs (machining residues);
 - Before proceeding with the installation, it is necessary to remove the rubble and the material deposited during the construction of the shaft.
 - Only nuts and bolts included in the supply must be used.
 - The bags containing the screws must be opened in correspondence with the respective operating phases indicated in this manual.
 - The instructions described in this manual refer to a reinforced shaft, to a fastening with mechanical expansion plugs of the stud type. For the use of plugs in masonry other than the reinforced concrete see the attachment to this manual. For the shafts with metal framework, we proceed by replacing the plugs with normal screws.
 - In these instructions and on the wiring diagram, the stops are indicated with 0, 1, 2, 3, meaning "0" the lowest stop: the numbers on the push-button panels may be different according to the user's needs (for example- 1, 0, etc.).




The assembly must be performed by a **MINIMUM 2** people;

If the load is greater than 50kg, use the hoist for handling.






1.2. INSTALLATION SITE - COMPONENTS POSITIONING



NOTICE

COMPONENTS POSITIONING:


It is important to position the material correctly on the installation site since once the scaffolding has been assembled it could become difficult to move some components, with the risk of injury and damage to the materials.



- a. Protect the floor during assembly.


2. PRODUCT DESCRIPTION

2.1. GENERAL DESCRIPTION AND TERMINOLOGY



IDEA CAR


Aluminum car
covered with
laminate panels.



OPERA CAR


Aluminum car
covered with
laminate slats
interspersed with
metal strips.

view from outside the cabin




Ceiling
C.O.P.
Mirror
Handrail
Profiles
Walls
Floor

view from inside the car



Car door

Frontals



WALL COVERING

HANDRAIL

C.O.P. (COLUMN)


FLOOR COVERING

CIELING

FRONT

WALLS

BASEMENT

2.2. COMPONENTS IDENTIFICATION




LIFTINGITALIA S.r.l.

Via Caduti del Lavoro, 16 - 43058 Bolognese, Sorbolo (PR) - Italy
Phone +39 0521.695311 - Fax +39 0521.695313



LIFTINGITALIA[®]

COMFORTABLE HOMELIFTS

INFORMATION


3. TOOLS AND MATERIALS REQUIRED FOR INSTALLATION



Tape measure



Spirit level




Hoist
150 kg




Double-sided adhesive



Spanner
8 to 17 mm
2 each size





Socket wrench
8 to 17 mm



Ratcheting ring spanner
13 to 17 mm



Allen key
with ball end
3 to 6 mm














Silicone (not included)
and Caulking gun

INFORMAZIONI

4. BOX CONTENT - SCREWS KIT



NOTE: Each "KIT" box with its identification code represents the packaging unit, i.e. how many pieces per type are contained in each package..





LIFTINGITALIA S.r.l.

Via Caduti del Lavoro, 16 - 43058 Bolognese, Sorbolo (PR) - Italy
Phone +39 0521.695311 - Fax +39 0521.695313



LIFTINGITALIA
COMFORTABLE HOMELIFTS

Optional

KIT D003.23.0001



2X
TCEI M6X20




2 x



2X
M8X10

KIT C002.23.0023



17X
M8X20



7X
M8



3X
M5



3X
M5X10



6X
M6X16




4X
Ø8



6X
M6

KIT C002.23.0009 - C002.23.0015



4 x

8 x

8 x

8 x

8 x



M10x20



Ø10




Ø10-Ø30



M10

LAYOUTS





5. BASEMENT ASSEMBLY




NOTICE


The car BASEMENT must be completely installed, before proceeding with the car assembly.

BASEMENT ASSEMBLY WITH PIT \geq 140 mm

- Install the basement using the pre-arranged holes.




KIT F350.23.0004




BASEMENT ASSEMBLY WITH 100 mm \leq PIT < 140 mm


- Install the basement using the pre-arranged holes.



KIT F350.23.0004



KIT C002.23.0009 / 0015





6. CAR ASSEMBLY



NOTICE



Before proceeding with the car assembly, make sure **the BASEMENT** is perfectly leveled.

6.1. UPRIGHT PREPARATION

- Install the slide on the upright using the pre-arranged bracket



KIT C002.23.0002






LIFTINGITALIA S.r.l.

Via Caduti del Lavoro, 16 - 43058 Bolognese, Sorbolo (PR) - Italy
Phone +39 0521.695311 - Fax +39 0521.695313




LIFTINGITALIA
COMFORTABLE HOMELIFTS

- a. Install the barrier on the pre-arranged upright



- Follow the assembly drawing to install the FRONTS, the WALLS, and the ANGLES.




INFORMATION

This manual applies to a single entrance car. To check the installation steps, please consult the project drawings enclosed with the scope of the supply.


The installation is to be started from the front left upright, following clockwise.

If the floor is supplied by the client, it is necessary to verify that the thickness of the floor is in accordance to the indicated information in the final drawing and in the project documentation.

6.2. UPRIGHTS FIXING TO THE BASEMENT



KIT C002.23.0010



Follow the below sequence of steps to install the uprights.



LIFTINGITALIA S.r.l.


Via Caduti del Lavoro, 16 - 43058 Bolognese, Sorbolo (PR) - Italy
Phone +39 0521.695311 - Fax +39 0521.695313




LIFTINGITALIA
COMFORTABLE HOMELIFTS

6.3. WALL FIXING



a. to UPRIGHTS



a. to ANGLES




KIT C002.23.0010



It is possible to preassemble the front uprights and the angles onto the walls, especially in case of limited shaft dimensions.

- Install the front CROSSBEAM (KIT C002.23.0010).





6.4. CEILING - MOUNTING

- Position the CEILING.

INFORMATION




Remove the central panel from the ceiling before the installation.



6.5. ACCESS TO THE SHAFT IN THE PRESENCE OF SUSPENDED CEILING

INFORMATION

The counter ceiling is supplied pre-installed and pre-wired.



- remove the fastening screws from one side of the counter-ceiling ①
- release the safety carabiner ②
- completely fold the countertop to access the platform roof ③.




LIFTINGITALIA S.r.l.

Via Caduti del Lavoro, 16 - 43058 Bogene, Sorbolo (PR) - Italy
Phone +39 0521.695311 - Fax +39 0521.695313




LIFTINGITALIA
COMFORTABLE HOMELIFTS

- Fix the ceiling onto the walls.




KIT C002.23.0010




INFORMATION

It is possible to preassemble the cage nuts in the wall holes.

- Fix the ceiling to the front crossbeam.





KIT C002.23.0010



NOTICE

When the "OVERHEAD PROTECTION DEVICE" is present, the safety microcontact must also be installed on the car roof (connected to the roof opening alarm siren).

- Fix the walls to the basement.



INFORMATION

It is possible to pre-assemble the cage nuts on the slots of the walls.

NOTICE

Any split between the components is to be eliminated.

Check the joints and tighten them, if necessary.





LIFTINGITALIA S.r.l.

Via Caduti del Lavoro, 16 - 43058 Bolognese, Sorbolo (PR) - Italy
Phone +39 0521.695311 - Fax +39 0521.695313



LIFTINGITALIA
COMFORTABLE HOMELIFTS



- Fix the cover to the crossbeam.





The cover is not foreseen in case of automatic doors.

FOR GLASS WALL FINISHED CAR



- Fix the cover to the angles.



- Fix the protection panel on the access sides.



- Fix the vertical protection on the slide side.






LIFTINGITALIA S.r.l.

Via Caduti del Lavoro, 16 - 43058 Bogene, Sorbolo (PR) - Italy
Phone +39 0521.695311 - Fax +39 0521.695313




LIFTINGITALIA
COMFORTABLE HOMELIFTS

- Remove the protection panel from the lamps on the COP side (if foreseen);





- Install the plate with the pre-installed components onto the panel;




- Install the lamps from inside the car;
- Put the protection panel back in its housing.

INFORMATION

Follow the electrical scheme.




- Replace the central panel of the ceiling.




INFORMATION

For safety contacts connection, consult the electrical scheme.



- Install the C.O.P. contact.



- Fix the C.O.P. in the car.





KIT C002.23.0004



INFORMATION

For safety contacts connection, consult the electrical scheme.

KIT C002.23.0014



INFORMATION

Pay attention when handling the C.O.P. to avoid damaging the ceiling.

For electrical components connection, consult the electrical scheme.



LIFTINGITALIA S.r.l.


Via Caduti del Lavoro, 16 - 43058 Bogene, Sorbolo (PR) - Italy
Phone +39 0521.695311 - Fax +39 0521.695313





LIFTINGITALIA
COMFORTABLE HOMELIFTS

6.6. HANDRAIL - INSTALLATION


ALUMINUM HANDRAIL - INSTALLATION





- Fix the inserts to the wall using the supplied screws (C).
- Insert the handrail and fix it using the grub screws provided inside the KIT (D).



KIT D003.23.0001



- Adjust the car holding brackets (already fitted – see the manual) and fix them inside the slots on the car ceiling.





LIFTINGITALIA S.r.l.

Via Caduti del Lavoro, 16 - 43058 Bolognese, Sorbolo (PR) - Italy
Phone +39 0521.695311 - Fax +39 0521.695313




LIFTINGITALIA[®]
COMFORTABLE HOMELIFTS



7. CAR DOOR DRIVE SPECIAL FIXING



FERMATOR - 40/10 DC 24 V - CAR DOOR DRIVE






LIFTINGITALIA S.r.l.

Via Caduti del Lavoro, 16 - 43058 Bolognese, Sorbolo (PR) - Italy
Phone +39 0521.695311 - Fax +39 0521.695313




LIFTINGITALIA[®]
COMFORTABLE HOMELIFTS

WITTUR HYDRA 3000 CAR DOOR DRIVE



WITTUR MDS1 CAR DOOR DRIVE





LIFTINGITALIA S.r.l.

Via Caduti del Lavoro, 16 - 43058 Bogene, Sorbolo (PR) - Italy
Phone +39 0521.695311 - Fax +39 0521.695313



LIFTINGITALIA

COMFORTABLE HOMELIFTS



LIFTING ITALIA S.r.l.

Via Caduti del Lavoro, 16
43058 Bogoiese di Sorbolo - Parma, Italy
Tel. +39 0521 695311

www.liftingitalia.com



AREALIFT S.r.l.

Via Caduti del Lavoro, 22
43058 Bogoiese di Sorbolo - Parma, Italy
Tel. +39 0521 695311

www.arealift.com

info@arealift.com



TECHNICAL SUPPORT

Tel. +39 0521 695328
support@liftingitalia.com