

# DomoFlex® and IconLift®

*Electric screw driven platform lift*


---

## ELECTRICAL EQUIPMENT (U.D.E.C.) INSTALLATION AND DIAGNOSTICS

---

(Rev.1.1)

sample image



**AREALIFTING®**

THE VERTICAL MOBILITY MANUFACTURER

# **DomoFlex 2<sup>®</sup> and IconLift<sup>®</sup>**

U.D.E.C. - INSTALLATION AND DIAGNOSTICS

20250508

## TABLE OF CONTENTS

|   |           |
|---|-----------|
| <b>1. Manual reading guide</b>                                  | <b>5</b>  |
| 1.01. Preliminary information                                   | 5         |
| 1.02. Personal security and risk recognition                    | 6         |
| <b>2. Safety and information Signs</b>                          | <b>7</b>  |
| 2.01. DANGER Signs  | 7         |
| 2.02. PROHIBITION Signs   | 7         |
| 2.03. MANDATORY Signs   | 7         |
| 2.04. Information symbols and infographics                      | 7         |
| <b>3. Liability and warranty conditions</b>                     | <b>8</b>  |
| <b>4. General requirements and installation site management</b> | <b>9</b>  |
| 4.01. General requirements                                      | 9         |
| <b>5. Overview DomoFlex 2</b>                                   | <b>10</b> |
| <b>6. Main electronic devices</b>                               | <b>11</b> |
| 6.01. Auxiliary power supply (PS1)                              | 11        |
| 6.02. Battery charger (PS2)                                     | 11        |
| 6.03. Pit board UDEC.P  | 11        |
| 6.04. Inverter MX2  | 12        |
| 6.05. Main board UDEC.M (see §16 for details)                   | 12        |
| 6.06. Landing door board UDEC.D (see §17 for details)           | 13        |
| 6.07. Platform / Cabin board UDEC.C (see §18 for details)       | 13        |
| <b>7. First run connections</b>                                 | <b>14</b> |
| <b>8. Magnets' layout</b>                                       | <b>15</b> |
| 8.01. With Aluminium rails                                      | 15        |
| 8.02. With Iron rails   | 16        |
| <b>9. Acoustic signal</b>                                       | <b>19</b> |
| <b>10. Reset &amp; Soft reset</b>                               | <b>19</b> |
| <b>11. Operating modes</b>                                      | <b>20</b> |
| <b>12. Power supply management</b>                              | <b>21</b> |
| <b>13. CAN communication management</b>                         | <b>21</b> |
| <b>14. LEDs on UDEC.A board</b>                                 | <b>22</b> |
| <b>15. Insulation tests</b>                                     | <b>23</b> |
| <b>16. Mainboard UDEC.M input / output diagnostic</b>           | <b>24</b> |
| 16.01. Inputs   | 24        |
| 16.02. Outputs  | 29        |
| <b>17. Landing door board UDEC.D input / output diagnostic</b>  | <b>32</b> |
| 17.01. Inputs   | 32        |
| 17.02. Outputs  | 33        |

|  |           |
|--|-----------|
| <b>18. Cabin / Platform board UDEC.C input / output diagnostic .....</b> | <b>35</b> |
| 18.01. Inputs .....  | 35        |
| 18.02. Outputs .....   | 38        |
| <b>19. Error codes and troubleshooting .....</b>                         | <b>40</b> |
| <b>20. HMI menu and parameters .....</b>                                 | <b>45</b> |
| 20.01. Menu - Section 'Parameter' Details .....                          | 46        |

## 1. Manual reading guide

### IMPORTANT!



#### EN: Translation of the original instructions

This product may only be commissioned if these instructions are available to you in an official EU language that you understand and you have understood the contents. If this is not the case, please contact your Lifting Italia S.r.l. contact partner.

### READ THIS MANUAL CAREFULLY

### BEFORE INSTALLING AND USING THE PRODUCT

Retain the technical documentation near the lifting platform for the entire lifecycle of the product. In case of change of ownership, the technical documentation must be provided to the new user as an integral part of the product.

## 1.01. Preliminary information

### NOTICE



This product must be installed and put into operation according to the provisions and regulations in force. Improper installation or improper use of the product can cause damage to people and property, as well as cause the warranty to lapse.

#### FOLLOW THE SUGGESTIONS AND RECOMMENDATIONS TO OPERATE IN SAFETY.

Any unauthorized modification can compromise the safety of the system, as well as the correct operation and the life of the machine. If you have any doubts regarding the correct understanding of the information and contents contained in this manual, contact LIFTING ITALIA S.r.l. immediately.

#### QUALIFIED PERSONNEL.

The product covered by this documentation can only be installed by qualified personnel, in compliance with the attached technical documentation, above all in compliance with the safety warnings and the precautions contained therein.



Technical specifications may be subject to change without notice due to product improvement development.

The drawings included in this manual are to be considered as indicative and are NOT an exact reference to the product concerned.

## 1.02. Personal security and risk recognition

This manual contains safety rules that must be observed to safeguard personal safety and to prevent damage to the property.

The indications to be followed to guarantee personal safety are highlighted by a triangle symbol while those to avoid material damage are not preceded by the triangle. The hazard warnings are shown as follows and indicate the different levels of risk in descending order.

| RISK CLASSIFICATION AND RELATIVE GRAVITY OF DAMAGE |  |
|--|--|
| <b>DANGER!</b>                                     | The symbol indicates that the failure to comply with appropriate safety measures causes death or serious physical injury.                      |
| <b>WARNING</b>                                     | The symbol indicates that the failure to observe the corresponding safety measures can cause death or serious personal injury.                 |
| <b>CAUTION</b>                                     | The symbol indicates that failure to observe the relevant safety measures can cause minor or moderate personal injury or damage to the device. |
| <b>NOTICE</b>                                      | It is not a symbol of security. It indicates that the failure to comply with relevant safety measures can result in property damage.           |
| <b>INFORMATION</b>                                 | It is not a symbol of security. It indicates important information.  |

RISIKONIVEAU

If there are multiple levels of risk, the danger warning always indicates the highest one. If a warning is drawn with a triangle to warn of the risk of injury to persons, the risk of possible property damage may also be caused at the same time.

| WARNING   |   |
|---|---|
|  | During installation / maintenance of the platform, the safety functions are temporarily suspended. Therefore all necessary precautions must be taken to avoid personal injury and / or damage to the product. |

## 2. Safety and information Signs

### 2.01. DANGER Signs

|   |                           |   |                        |   |                           |
|---|---------------------------|---|------------------------|---|---------------------------|
|  | GENERAL DANGER            |  | ELECTRICITY DANGER     |  | DANGER FLAMMABLE MATERIAL |
|  | DANGER OF FALL BY A LEVEL |  | DANGER SUSPENDED LOADS |  | DANGER OF CRUSHING        |

### 2.02. PROHIBITION Signs

|   |                     |   |                      |   |  |
|---|---------------------|---|----------------------|---|--|
|  | GENERIC PROHIBITION |  | FORBIDDEN TO STEP ON |  | PROHIBITED TO WALK ON OR STOP IN THIS AREA |
|---|---------------------|---|----------------------|---|--|

### 2.03. MANDATORY Signs

|  |  |  |   |   |                                       |
|--|--|--|---|---|---------------------------------------|
|   | OBLIGATORY TO WEAR THE PROTECTION HELMET |   | OBLIGATORY TO WEAR SAFETY SHOES         |  | OBLIGATORY WEAR THE PROTECTIVE GLOVES |
|  | OBLIGATORY TO WEAR EYE PROTECTION        |  | OBLIGATION TO WEAR THE AUDIO PROTECTION |   |                                       |

### 2.04. Information symbols and infographics

|   |                |   |                    |   |                         |
|---|----------------|---|--------------------|---|-------------------------|
|  | MARK           |  | DRILL AND/OR SCREW |  | CUTTING AND/OR GRINDING |
|  | MEASURE        |  | APPLY RIVETS       |  | USE SUCTION CUPS        |
|  | USE THE HAMMER |  | LEVELING           |  | USE HOIST               |

|   |   |
|---|---|
|  | <b>INFORMATION</b><br>Symbol that identifies information that is useful to the installer but is not mandatory for the installation, nor does it pose a risk to the user.. |
|  | <b>IMPORTANT!</b><br>Symbol that identifies important information to be scrupulously observed.  |
|  | <b>ELECTRICAL CONNECTIONS</b><br>Symbol that identifies the connection of an electrical component.  |

### 3. Liability and warranty conditions

#### RESPONSIBILITY OF THE INSTALLER

##### IMPORTANT!



Installers are responsible for ensuring compliance with safety procedures at work and any health and safety regulations in force in the country and on the site where the assembly is carried out.

The persons authorized to carry out installation, maintenance, and rescue operations are those in possession of an elevator maintenance authorization certificate, issued according to the regulations in force in the country where the assembly is carried out.

The elevator / platform (and each of its components) is produced and intended to be installed as described in the attached project drawing and in this manual; any divergence from the prescribed procedure may affect the operation and safety of the system and cause the immediate cancellation of the warranty.

Any modification or variation made to the project and the assembly Instructions must be documented in detail and referred to LIFTING ITALIA S.r.l., in order to allow the company an adequate assessment. Under no circumstances can a modified system be activated without the express authorization of LIFTING ITALIA S.r.l.

The elevator / platform must only be used in the way envisaged by the system and illustrated in the relative manuals (transportation of people and / or things, maximum loads, cycles of use, etc.). LIFTING ITALIA S.r.l. assumes no responsibility for damage to persons and property caused by improper use of the system.



Pictures and images on this manual are for illustration purposes only.

## 4. General requirements and installation site management

### 4.01. General requirements

#### IMPORTANT!



For more information on safety, liability and warranty conditions, receipt and storage of material on site, packaging, waste disposal, cleaning and storage of the product; refer to the "SAFETY INSTRUCTIONS AND SITE MANAGEMENT" manual.

#### NOTICE



##### PRELIMINARY CHECKS.

Once the packaging has been opened, check that the product is intact and has not been damaged during transport. Should any anomalies or damage be found, please dispatch them in writing on the transport document to the transport company, giving written notice to LIFTINGITALIA S.r.l.

#### WARNING



##### SAFETY AND SITE MANAGEMENT - OVERALL DISPOSITIONS:

1. Always secure tools and any objects against falling;
  2. Pay the utmost attention to all the steps described in this;
  3. While assembling the parts making up the system or after installation, be careful of any sharp burrs (machining residues).
- Before proceeding with the installation, it is necessary to remove any rubble and material deposited during the construction of the shaft.
  - Only nuts and bolts included in the supply must be used.
  - The bags containing the screws must be opened in correspondence with the respective operating phases indicated in this manual.
  - The instructions described in this manual refer to a reinforced shaft, to a fastening with mechanical expansion plugs of the stud type. For the use of plugs in masonry other than the reinforced concrete see the attachment to this manual. For the shafts with metal framework, we proceed by replacing the plugs with normal screws.
  - In these instructions and on the wiring diagram, the stops are indicated with 0, 1, (2, 3 etc.), meaning "0" the lowest stop: the numbers on the push-button panels may be different according to the user's needs (for example - 1, 0, etc.).

#### CAUTION



The assembly must be performed by a  
MINIMUM 2 people




Use a suitable lifting equipment for handling  
the components if the load is greater than  
50kg

## Overview DomoFlex 2

The electrical equipment of DomoFlex 2 consists of the following main components and connections:


- ① Main control panel integrated in the frame of the lowest door.
- ② Cabin electronic board and inverter box located on the platform.
- ③ Landing doors' electronic boards located in the door frame.
- Ⓐ The platform is connected to the control panel by flexible cables, one reserved for the inverter and one for the cabin board.
- Ⓑ The door boards are connected together by a single cable.
- Ⓒ The pit devices are connected directly to the main control panel.



## 5. Main electronic devices


### 5.01. Auxiliary power supply (PS1)

- ① Input for 230V AC.
- ② Output 24V DC for command and auxiliary devices.
- ③ Output voltage trimmer.




### 5.02. Battery charger (PS2)

- ① Fuse 6A for batteries.
- ② Supply voltage present.
- ③ Emergency power supply activated.




### 5.03. Pit board UDEC.P

- ① Batteries connection.
- ② Emergency motor connection.
- ③ Batteries fuse.
- ④ Pit safeties connections.
- ⑤ Pit access LED and buzzer.




### 5.04. Inverter MX2

- 1 Power terminals.
- 2 Control terminals.
- 3 Display – buttons.
- 4 Configuration dipswitches.




### 5.05. Main board UDEC.M (see §16 for details)

- 1 Human-Machine-Interface (HMI).
- 2 Movement commands.
- 3 Connection to shaft.
- 4 Connectors to platform.
- 5 Safeties collector.
- 6 Auxiliary input/outputs.




## 5.06. Landing door board UDEC.D (see §17 for details)

- P1** **P3** Input / output connections to other landing door boards.
- P2** Door lock contacts.
- P4** Display.
- P5** Electric lock output.
- P6** Automatic door operator.
- P7** Electric lock input.
- P8** **P9** **P10** Pushbuttons / key-switches.




## 5.07. Platform / Cabin board UDEC.C (see §18 for details)

- 1** Car safeties.
- 2** COP pushbuttons.
- 3** Position sensors.
- 4** Car doors.



## 6. First run connections

- D. Make all connections between the platform and the switchboard as shown on the wiring diagram.  
 E. Temporarily bridge the contacts of the equipment not yet connected using the terminals provided and connect the maintenance control station following the directions below:



| LEGENDA  |   |
|----------|---|
| ST_MON   | Emergency stop on the maintenance control station             |
| MAN-DISC | Down button on the maintenance control station                |
| MAN-SAL  | Up button on the maintenance control station                  |
| SA-MAN   | Maintenance selector switch (contact closed > maintenance on) |

- F. Make all ground connections.  
 G. Check that all safeties are closed and that the emergency stop on the car operating panel is working properly.  
 H. To activate operation in maintenance, turn the selector switch to the MAN position.

In maintenance, the system moves only through the SB\_DN and SB\_UP controls: holding down the former causes the car to move downward while the latter causes it to move upward.


|  |  |
|--|--|
|  | To switch from maintenance to normal, reference must be made to § 11 OPERATING MODES   |
|  | During the assembly operation, there is no control of the position of the cabin. Only if all the magnets have been properly installed and the system is rephased, the movement in maintenance is limited to the stroke of the system, between the extreme floors.. |

## 7. Magnets' layout


### 7.01. With Aluminium rails

Adjust magnets position:

1. With the system under maintenance, bring the car to the exact floor level (floor and car levels aligned);
2. Check that the magnet holder plates are positioned at a height of 840mm respect to the landing level. The holder plate must be aligned with the magnetic sensors and the electrolock slide located rear the car operating panel;



3. Adjust magnets position (IS, ID e IR) as shown in the picture;



4. Repeat the procedure at the other landings.

|   |  |
|---|--|
|  | IR magnet is present only at the lowest level. |
|---|--|

## 7.02. With Iron rails

### CAUTION




TWO ASSEMBLERS ARE NEEDED: one in the machine room in front of the control panel and the other near the sensors.

Adjust magnets position following this procedure:


1. With the system under maintenance, bring the car to the exact floor level (floor and car levels aligned);
2. IS ascent sensor: gradually move from the top the 150 mm magnet towards the sensor, stopping just as the corresponding IS LED on the card turns on;
3. ID descent sensor: gradually move from the bottom the 150 mm magnet to the sensor, stopping just as the corresponding ID LED on the card turns on.



Pictures may slightly differ from the machine.










Hereunder, the recommended sensor location.




#### LEGEND

|       |                                    |
|-------|------------------------------------|
| IR    | Re-phasing sensor                  |
| ID    | Descent sensor (stop and slowdown) |
| IS    | Ascent sensor (stop and slowdown)  |
| PB    | Lowest floor                       |
| PI    | Intermediate floors                |
| PA    | Upper floor                        |
| ZB    | Bypass zone                        |
| Rall. | Slowdown distance                  |



# DomoFlex 2® and IconLift®

U.D.E.C. - INSTALLATION AND DIAGNOSTICS



## 8. Acoustic signal

During the operation the platform may emit some acoustic signals to warn the user:

|                        |  |
|------------------------|--|
| <b>CONTINOUS</b>       | The platform / car safeties have been activated. Check the safety edges.                         |
| <b>CONTINOUS BEEPS</b> | Overload.  |
| <b>2 BEEPS</b>         | The user is trying to move the platform but one of the doors is not completely closed or locked. |
| <b>3 BEEPS</b>         | The user is trying to move the platform but one of the emergency stops is engaged.               |

## 9. Reset & Soft reset

There are two kinds of reset commands:

|                   |  |
|-------------------|--|
| <b>RESET</b>      | Press both the arrow buttons on the HMI inside the control panel for more than three seconds. The display will show a message to confirm that the operation is running ("RESET RUNNING").<br>See §19 to check what errors must be reset by this command. |
| <b>SOFT RESET</b> | Press both call buttons on one of the COPs for more than five seconds. The maximum number of soft resets is three; once this number is reached a standard reset is required.<br>See §19 to check what errors can be reset by this command.               |


## 10. Operating modes

The technician can switch between the different operating modes using the HMI (see §20).

The switch between normal and blackout mode is automatic, depending on the grid and platform status.

|                                    |   |
|------------------------------------|---|
| <b>NORMAL</b>                      | If the platform commands are enabled and no error is present, the local and remote commands can be used to move the platform.   |
| <b>BLACK-OUT<br/>POWER FAILURE</b> | <p>During a blackout the behaviour of the platform depends on its position:</p> <ul style="list-style-type: none"> <li>at the floor: the platform will stay at the floor until the main supply is restored. All the commands will unlock the landing door.</li> <li>not at the floor: after few seconds all the commands received from the COP will move the platform downward in low speed to the nearest landing.</li> </ul>  |
| <b>MAINTENANCE</b>                 | <p>Once in this mode, the landing and remote commands are disabled, and the platform can be operated only using the arrow buttons on the HMI or using the first two buttons on the COP (press ESC until the display shows "MAINTENANCE ACTIVE").</p> <p>If the platform has been re-phased moves between the limit positions in the same way as in normal mode. Otherwise, the upper limit is determined by the overtravel safety switch. The lower limit is always determined by the sensors and magnets IR and ID.</p> <div style="background-color: yellow; padding: 5px; text-align: center;"> <b>CAUTION</b> </div> <div style="display: flex; align-items: center;">  <ul style="list-style-type: none"> <li>This operating mode can cause physical damage to the user / technician or damage the machine.</li> <li>Be extremely careful when using these functions.</li> </ul> </div> |
| <b>COMMISSIONING</b>               | <p>As in maintenance mode, all local and remote commands are disabled.</p> <ul style="list-style-type: none"> <li>Overtravel commissioning: the platform can be operated using the HMI arrow buttons; it will move only in low speed ignoring the state of the limit switches. During the movement the platform will emit an acoustic signal to warn the technicians.</li> </ul> <p>Use this mode to test the safety switch for overtravel or if there are problems related to the position sensors.</p>  |

## 11. Power supply management

|  |  |
|--|--|
| <p>The main board UDEC.M receives the 24V DC voltage supply and distributes it to the other electronic devices monitoring the voltage outputs to detect short circuits or overloads.</p> |  |
|--|--|

If any fault is detected the main board turns off one or more outputs, depending on the fault (see §19 ERR\_A00x). At the start-up the main board turns on in sequence the four supply outputs to test for possible short circuits. The other electronic boards (door and cabin) have intrinsic mechanisms for the power supply management. In case of errors these boards are automatically reset by the main board for a limited number of times. Once the maximum number of automatic resets is exceeded the main board needs a reset (see §19 ERR\_Dn05).

This is the quick procedure for troubleshooting in case of errors related to the power supply:

- disconnect all the plugs from the board;
- reset the board;
- connect the plugs one at a time and wait for the error to occur;
- when the error occurs check the devices and cables connected to that plug.

## 12. CAN communication management


The intelligent boards communicate on a CAN bus network exchanging messages related to the IOs state, commands, diagnostics etc.

The protocol has intrinsic mechanisms to automatically detect and recover from communication errors. In case of temporary disconnection of a remote board (UDEC.D or UDEC.C) from the bus the main board UDEC.M can inhibit some functionalities, but these are automatically restored when the remote board returns alive.

If the number of communication anomalies detected exceeds a defined threshold, the main board requests a reset (see §19 ERR\_Dn11).

## 13. LEDs on UDEC.A board

The following image and table explain the meaning of the LEDs found on the door board UDEC.A:



| LED UDEC.A | LED UDEC.C (2nd door) | Contact   | Signal label | Description            |
|------------|-----------------------|-----------|--------------|------------------------|
| PADX       | PC11 (PC7)            | SQ-PCA-DX | A            | Right door leaf open   |
| PCDX       | PC10 (PC6)            | SQ-APC-DX | B            | Right door leaf closed |
| PASX       | PC13 (PC9)            | SQ-PCA-SX | C            | Left door leaf open    |
| PCSX       | PC12 (PC8)            | SQ-APC-SX | D            | Left door leaf closed  |


## 14. Insulation tests

- A. Place the car between two floors and check if the safety chain is closed.
- B. Disconnect the control panel from the mains supply by opening the power switchgears (QS, QF-3, QF-4).
- C. Disconnect all the battery terminals.
- D. To avoid a wrong result or the damaging of the equipment, disconnect the power supply from the devices that are connected to PE: inverter, LEDs supply units, etc.
- E. Disconnect the “-” conductor from the PE terminal on Xr; the terminal is shown on the electrical drawings.
- F. Make sure that all the low voltage switchgears inside the cabinet are closed (QF-24 and QF-SER).
- G. Measure the resistance values between PE and the terminals indicated in the below table. The table shows the test voltage (V) and the minimum resistance of the insulation between the circuits ( $M\Omega$ ).

|    | 10L and 10N          | LC-L and LC-N        | LV-L and LV-N        | +24VO                  | +24VA<br>+24VM<br>+24VV<br>+24VC |
|----|----------------------|----------------------|----------------------|------------------------|----------------------------------|
| PE | 500V<br>$> 1M\Omega$ | 500V<br>$> 1M\Omega$ | 500V<br>$> 1M\Omega$ | 250V<br>$> 0.5M\Omega$ | 250V<br>$> 0.5M\Omega$           |

- H. Restore all the connections.

## 15. Mainboard UDEC.M input / output diagnostic



The standby status refers to platform at the bottom floor ready to serve a call.

In case of incorrect status, for all the inputs/outputs:

- Check the voltage directly on the connector pin;
  - Check if the connector / wire is properly inserted in the plug;
  - Try to make a temporary bridge or to remove the wire to check if the LED status changes.

15.01. Inputs

|             |                          |   |
|-------------|--------------------------|---|
| <b>P0.4</b> | Label                    | 24VIN   |
|             | Description              | 24V DC input voltage supply   |
|             | Standby status           |  ON  |
|             | If status is not correct | <ul style="list-style-type: none"><li>A. Check the switchgears QS and QF-24.</li><li>B. Check the power supply PS1.</li><li>C. Check the platform power supply.</li></ul> |

|             |                          |  |
|-------------|--------------------------|--|
| <b>P0.2</b> | Label                    | GRID-OK  |
|             | Description              | Grid voltage 230V AC detected  |
|             | Standby status           |  ON   |
|             | If status is not correct | <ul style="list-style-type: none"><li>A. Check the switchgear QF-3.</li><li>B. Check the platform power supply.</li><li>C. Check the power supply PS1.</li></ul> |

|             |                          |  |
|-------------|--------------------------|--|
| <b>P0.1</b> | Label                    | <b>BAT-KO</b>  |
|             | Description              | Batteries discharged or disconnected   |
|             | Standby status           |  OFF  |
|             | If status is not correct | <ul style="list-style-type: none"><li>A. Check the status of the batteries.</li><li>B. Check the connection of the batteries to the control panel.</li><li>C. Check the status of the LEDs on the battery charger.</li></ul> |

|              |                          |  |
|--------------|--------------------------|--|
| <b>P20.1</b> | Label                    | S1-IN  |
|              | Description              | Safety chain - INPUT   |
|              | Standby status           |  ON |
|              | If status is not correct | A. Check the circuit breaker QF-SER.   |

|              |                          |   |
|--------------|--------------------------|---|
| <b>P60.1</b> | Label                    | S2-OVT  |
|              | Description              | Safety chain - OVERTRAVEL   |
|              | Standby status           |  ON  |
|              | If status is not correct | A. Check the status of input S1-IN.<br>B. Check the safety switches SQ-EXC.<br>C. Check the connections between the control panel and the switches. |

|              |                          |  |
|--------------|--------------------------|--|
| <b>P61.2</b> | Label                    | S3-PIT   |
|              | Description              | Safety chain - PIT safety devices  |
|              | Standby status           |  ON   |
|              | If status is not correct | A. Check the status of input S2-OVT.<br>B. Check the safety switches SQ-PEF and SQ-FF.<br>C. Check the connections between the control panel and the switches. |

|              |                          |  |
|--------------|--------------------------|--|
| <b>P70.2</b> | Label                    | S4-CAB   |
|              | Description              | Safety chain - CABIN safety devices  |
|              | Standby status           |  ON   |
|              | If status is not correct | A. Check the status of input S3-PIT.<br>B. Check the car safety inputs on UDEC.C (see §18).<br>C. Check the connections between the control panel and car. |

|              |                          |  |
|--------------|--------------------------|--|
| <b>P60.5</b> | Label                    | S5-FPC   |
|              | Description              | Safety chain - Landing doors Preliminary Contact   |
|              | Standby status           |  ON   |
|              | If status is not correct | A. Check the status of input S4-CAB.<br>B. Check the safety contacts SQ-APP-Pn.<br>C. Check the connections between the control panel and the landing doors. |

|              |                          |  |
|--------------|--------------------------|--|
| <b>P70.4</b> | Label                    | S6-CPC   |
|              | Description              | Safety chain - Car doors Preliminary Contact   |
|              | Standby status           |  ON   |
|              | If status is not correct | A. Check the status of input S5-FPC.<br>B. Check the car safety inputs of the car doors on UDEC.C (see §18)<br>C. Check the connections between the control panel and the car. |

# DomoFlex 2® and IconLift®

## U.D.E.C. - INSTALLATION AND DIAGNOSTICS

|               |                          |   |
|---------------|--------------------------|---|
| <b>P60.3</b>  | Label                    | S7-LCK  |
|               | Description              | Safety chain - Landing doors LOCKS  |
|               | Standby status           |  ON  |
|               | If status is not correct | <ul style="list-style-type: none"> <li>A. Check the status of input S6-N.C.</li> <li>B. Check the safety contacts SQ-BLO-Pn.</li> <li>C. Check the connections between the control panel and the landing doors.</li> </ul>          |
| <b>P43.2</b>  | Label                    | S8-END  |
|               | Description              | Safety chain - END  |
|               | Standby status           |  ON  |
|               | If status is not correct | <ul style="list-style-type: none"> <li>A. Check the status of input S7-LCK</li> </ul>   |
| <b>P61.3</b>  | Label                    | SQ-SPF  |
|               | Description              | Not used  |
|               | Standby status           |  OFF   |
|               | If status is not correct | <ul style="list-style-type: none"> <li>A. Check the connections in the control panel.</li> </ul>  |
| <b>P61.4</b>  | Label                    | SQ-FFA  |
|               | Description              | Safe pit device - auxiliary contact (ON with safe pit inserted)   |
|               | Standby status           |  OFF   |
|               | If status is not correct | <ul style="list-style-type: none"> <li>A. Check the status of the contact SQ-FFA on the safe pit device.</li> <li>B. Check the connections between the control panel and contact.</li> </ul>  |
| <b>P70.9</b>  | Label                    | ID  |
|               | Description              | Position Reed input - ID (down direction)   |
|               | Standby status           |  ON  |
|               | If status is not correct | <ul style="list-style-type: none"> <li>A. Check the alignment between the sensor and the magnet.</li> <li>B. Check the connections between the board and the sensor.</li> <li>C. Check the input ID on the board UDEC.C.</li> </ul> |
| <b>P70.10</b> | Label                    | IS  |
|               | Description              | Position Reed input - IS (up direction)   |
|               | Standby status           |  ON  |
|               | If status is not correct | <ul style="list-style-type: none"> <li>A. Check the alignment between the sensor and the magnet.</li> <li>B. Check the connections between the board and the sensor.</li> <li>C. Check the input IS on the board UDEC.C.</li> </ul> |
| <b>P70.11</b> | Label                    | IP  |
|               | Description              | Not used  |
|               | Standby status           |  OFF   |
|               | If status is not correct | <ul style="list-style-type: none"> <li>A. Check the connections in the control panel.</li> </ul>  |

|               |                          |   |
|---------------|--------------------------|---|
| <b>P70.12</b> | Label                    | IR  |
|               | Description              | Position Reed input - IR (zero)   |
|               | Standby status           |  ON  |
|               | If status is not correct | A. Check the alignment between the sensor and the magnet.<br>B. Check the connections between the board and the sensor.<br>C. Check the input IR on the board UDEC.C. |

|              |                          |   |
|--------------|--------------------------|---|
| <b>P30.2</b> | Label                    | SB-MEM  |
|              | Description              | Pushbutton for emergency operation  |
|              | Standby status           |  ON  |
|              | If status is not correct | A. Check if the button is pressed / stuck.<br>B. Check the connections between the board and the button.<br>C. Check the status of output 24VA. |

|              |                          |   |
|--------------|--------------------------|---|
| <b>P31.2</b> | Label                    | BRK   |
|              | Description              | Brake input from the inverter (ON during the movement)  |
|              | Standby status           |  OFF                             |
|              | If status is not correct | A. Check if there is any command running.<br>B. Check the connections between the control panel and the inverter. |

|              |                          |  |
|--------------|--------------------------|--|
| <b>P31.1</b> | Label                    | INV-OK   |
|              | Description              | Inverter status  |
|              | Standby status           |  ON   |
|              | If status is not correct | A. Check the inverter status accessing to its display.<br>B. Check the connections between the control panel and the inverter. |

|              |                          |   |
|--------------|--------------------------|---|
| <b>P26.2</b> | Label                    | FBK-C   |
|              | Description              | Feedback from the contactors (OFF when OK-TO-RUN is ON)   |
|              | Standby status           |  ON  |
|              | If status is not correct | A. Check if any of the contactors is glued.<br>B. Check the status of 24VA.<br>C. Check the connections between the control panel and the contactors. |

|              |                          |  |
|--------------|--------------------------|--|
| <b>P42.2</b> | Label                    | FBK-EM   |
|              | Description              | Feedback from the emergency relays on UDEC.P (OFF when OK-TO-RUN is ON or with SB-MEM pressed)   |
|              | Standby status           |  ON   |
|              | If status is not correct | A. Check if any of the relay on UDEC.P is glued.<br>B. Check the status of 24VA.<br>C. Check the connections between the control panel and the board UDEC.P. |

# DomoFlex 2® and IconLift®

## U.D.E.C. - INSTALLATION AND DIAGNOSTICS

|              |                          |   |
|--------------|--------------------------|---|
| <b>P11.2</b> | Label                    | IN-3  |
|              | Description              | Not used  |
|              | Standby status           |  OFF   |
|              | If status is not correct | A. Check the connections in the control panel.  |
| <b>P11.3</b> | Label                    | IN-4  |
|              | Description              | Not used  |
|              | Standby status           |  OFF   |
|              | If status is not correct | A. Check the connections in the control panel.  |
| <b>P11.4</b> | Label                    | IN-5  |
|              | Description              | Not used  |
|              | Standby status           |  OFF   |
|              | If status is not correct | A. Check the connections in the control panel.  |
| <b>P50.2</b> | Label                    | IN-1  |
|              | Description              | Not used  |
|              | Standby status           |  OFF   |
|              | If status is not correct | A. Check the connections in the control panel.  |
| <b>P51.2</b> | Label                    | IN-2  |
|              | Description              | Not used  |
|              | Standby status           |  OFF   |
|              | If status is not correct | A. Check the connections in the control panel.  |
| <b>P52.2</b> | Label                    | SCREW   |
|              | Description              | Screw lifted switch   |
|              | Standby status           |  ON  |
|              | If status is not correct | A. Check the status of the switch SQ-VIT on the safe pit device.<br>B. Check the connections between the control panel and contact. |
| <b>P90.1</b> | Label                    | ALARM   |
|              | Description              | Alarm button status   |
|              | Standby status           |  OFF   |
|              | If status is not correct | A. Check if the alarm button on the COP is pressed.<br>B. Check the connections between the control panel and the COP.              |

## 15.02. Outputs

|              |                          |   |
|--------------|--------------------------|---|
| <b>P40.1</b> | Label                    | 24VA  |
|              | Description              | 24V DC Auxiliary output   |
|              | Standby status           |  ON                                |
|              | If status is not correct | A. Look for any short-circuit outside the control panel.<br>B. Look for any short-circuit inside the control panel. |

|             |                          |   |
|-------------|--------------------------|---|
| <b>P5.1</b> | Label                    | 24VM  |
|             | Description              | 24V DC Movement output  |
|             | Standby status           |  ON                                |
|             | If status is not correct | A. Look for any short-circuit outside the control panel.<br>B. Look for any short-circuit inside the control panel. |

|              |                          |   |
|--------------|--------------------------|---|
| <b>P60.7</b> | Label                    | 24VV  |
|              | Description              | 24V DC Shaft output   |
|              | Standby status           |  ON                                |
|              | If status is not correct | A. Look for any short-circuit outside the control panel.<br>B. Look for any short-circuit inside the control panel. |

|              |                          |   |
|--------------|--------------------------|---|
| <b>P70.5</b> | Label                    | 24VC  |
|              | Description              | 24V DC Car output   |
|              | Standby status           |  ON                              |
|              | If status is not correct | A. Look for any short-circuit outside the control panel.<br>B. Look for any short-circuit inside the control panel. |

|              |                          |  |
|--------------|--------------------------|--|
| <b>P22.2</b> | Label                    | OK-TO-RUN  |
|              | Description              | Command for the power contactors and brake enable.<br>ON during the movement or if the platform is not at the floor.   |
|              | Standby status           |  OFF  |
|              | If status is not correct | A. Look for any short-circuit outside the control panel.<br>B. Look for any short-circuit inside the control panel.<br>C. Check the connection of P21.4 and P20.2. |

|              |                          |   |
|--------------|--------------------------|---|
| <b>P24.4</b> | Label                    | UPWARD  |
|              | Description              | Command for the inverter - UPWARD.<br>ON during the movement upward.  |
|              | Standby status           |  OFF   |
|              | If status is not correct | A. Look for any short-circuit outside the control panel.<br>B. Look for any short-circuit inside the control panel.<br>C. Check the status of 24VM and the connection of P20.2. |

|              |                          |   |
|--------------|--------------------------|---|
| <b>P24.3</b> | Label                    | DOWNWARD  |
|              | Description              | Command for the inverter - DOWNWARD.<br>ON during the movement downward.  |
|              | Standby status           |  OFF   |
|              | If status is not correct | <ul style="list-style-type: none"> <li>A. Look for any short-circuit outside the control panel.</li> <li>B. Look for any short-circuit inside the control panel.</li> <li>C. Check the status of 24VM and the connection of P20.2.</li> </ul> |

|              |                          |   |
|--------------|--------------------------|---|
| <b>P24.2</b> | Label                    | HIGH SPEED  |
|              | Description              | Command for the inverter - HIGH SPEED.<br>ON during the movement in high speed.   |
|              | Standby status           |  OFF   |
|              | If status is not correct | <ul style="list-style-type: none"> <li>A. Look for any short-circuit outside the control panel.</li> <li>B. Look for any short-circuit inside the control panel.</li> <li>C. Check the status of 24VM and the connection of P20.2.</li> </ul> |

|              |                          |   |
|--------------|--------------------------|---|
| <b>P25.2</b> | Label                    | BRAKE   |
|              | Description              | Command for the BRAKE release.<br>ON during the movement.   |
|              | Standby status           |  OFF   |
|              | If status is not correct | <ul style="list-style-type: none"> <li>A. Look for any short-circuit outside the control panel.</li> <li>B. Look for any short-circuit inside the control panel.</li> <li>C. Check the status of 24VM and the connection of P20.2.</li> </ul> |

|                |                          |  |
|----------------|--------------------------|--|
| <b>P41.3/4</b> | Label                    | OUT-1  |
|                | Description              | Not used   |
|                | Standby status           |  OFF              |
|                | If status is not correct | <ul style="list-style-type: none"> <li>A. Check the connections inside the control panel.</li> </ul> |

|                |                          |  |
|----------------|--------------------------|--|
| <b>P41.1/2</b> | Label                    | OUT-2  |
|                | Description              | Not used   |
|                | Standby status           |  OFF              |
|                | If status is not correct | <ul style="list-style-type: none"> <li>A. Check the connections inside the control panel.</li> </ul> |

|              |                          |  |
|--------------|--------------------------|--|
| <b>P10.1</b> | Label                    | FLOOR  |
|              | Description              | Output for the "Car at floor" light.<br>ON with car at any landing floor.  |
|              | Standby status           |  ON   |
|              | If status is not correct | <ul style="list-style-type: none"> <li>A. Check the position sensors inputs (IR, IS, ID).</li> <li>B. Check the connections inside the control panel.</li> <li>C. Check the status of 24VA.</li> </ul> |


|              |                          |  |
|--------------|--------------------------|--|
| <b>P55.1</b> | Label                    | <b>EMERGENCY MOTOR</b>   |
|              | Description              | Command for the emergency operation motor.<br>ON during the automatic emergency operations (i.e., power failure).  |
|              | Standby status           |  OFF  |
|              | If status is not correct | <ul style="list-style-type: none"> <li>A. Check the GRID input.</li> <li>B. Check the status of the 230V AC power supply.</li> <li>C. Check the connections inside the control panel.</li> <li>D. Check the status of 24VA.</li> </ul> |

|              |                          |  |
|--------------|--------------------------|--|
| <b>P56.1</b> | Label                    | <b>INVERTER RESET</b>  |
|              | Description              | Command for inverter RESET.<br>ON when operating a reset from HMI or platform.   |
|              | Standby status           |  OFF  |
|              | If status is not correct | <ul style="list-style-type: none"> <li>A. Check the connections inside the control panel.</li> <li>B. Check the status of 24VA.</li> </ul> |

|              |                          |  |
|--------------|--------------------------|--|
| <b>P57.1</b> | Label                    | <b>LIGHT</b>   |
|              | Description              | Command for shaft lights.<br>ON during the movement or in error state.   |
|              | Standby status           |  OFF  |
|              | If status is not correct | <ul style="list-style-type: none"> <li>A. Check the inputs status starting from the safety chain.</li> <li>B. Check the connections inside the control panel.</li> <li>C. Check the status of 24VA.</li> </ul> |

|              |                          |   |
|--------------|--------------------------|---|
| <b>P61.5</b> | Label                    | <b>HL-FF</b>  |
|              | Description              | Pit access notification (light + buzzer).<br>ON when a pit access is detected.  |
|              | Standby status           |  OFF   |
|              | If status is not correct | <ul style="list-style-type: none"> <li>A. Check the inputs S3-PIT, S2-EXC and S1-IN.</li> <li>B. Check the input UNLOCK on the board UDEC.D of the lowest floor.</li> <li>C. Check the status of 24VA.</li> </ul> |

## 16. Landing door board UDEC.D input / output diagnostic



Before checking the LEDs check that the board is properly connected and powered.

### 16.01. Inputs

|             |                          |   |
|-------------|--------------------------|---|
| <b>P2.5</b> | Label                    | PREL.   |
|             | Description              | Safety chain - Landing door PRELIMINARY contact.<br>ON with gate closed.  |
|             | Standby status           | ON  |
|             | If status is not correct | <ul style="list-style-type: none"> <li>A. Check the status of input S4-CAB (UDEC.M).</li> <li>B. Check the safety contact SQ-APP-Px.</li> <li>C. Check the connections between the board and the contact.</li> <li>D. Check that the board is connected and powered.</li> </ul> |

|             |                          |  |
|-------------|--------------------------|--|
| <b>P2.8</b> | Label                    | LOCK   |
|             | Description              | Safety chain - Landing door LOCK contact.<br>ON with gate locked.  |
|             | Standby status           | ON   |
|             | If status is not correct | <ul style="list-style-type: none"> <li>A. Check the status of input S6. (UDEC.M).</li> <li>B. Check the safety contact SQ-BLO-Px.</li> <li>C. Check the connections between the board and the contact.</li> <li>D. Check that the board is connected and powered.</li> </ul> |

|             |                          |  |
|-------------|--------------------------|--|
| <b>P2.4</b> | Label                    | UNLOCK   |
|             | Description              | Landing door UNLOCK contact.<br>ON with gate unlocked.   |
|             | Standby status           | OFF  |
|             | If status is not correct | <ul style="list-style-type: none"> <li>A. Check the contact SQ-PR-Px.</li> <li>B. Check the connections between the board and the contact.</li> <li>C. Check that the board is connected and powered.</li> </ul> |

|             |                          |  |
|-------------|--------------------------|--|
| <b>P7.1</b> | Label                    | (no label)   |
|             | Description              | Supply for electric lock circuit (from shaft sliding contact)                                  |
|             | Standby status           |  OFF (no led) |
|             | If status is not correct | A. Check connections between the board and the SQ-Pn contact.                                  |

|             |                          |   |
|-------------|--------------------------|---|
| <b>P8.1</b> | Label                    | IN1   |
|             | Description              | Call pushbutton input.<br>ON with button pressed.   |
|             | Standby status           |  OFF   |
|             | If status is not correct | A. Check if the button is pressed / stuck.<br>B. Check the connections between the board and the button.<br>C. Check that the board is connected and powered. |

|             |                          |  |
|-------------|--------------------------|--|
| <b>P9.1</b> | Label                    | IN2  |
|             | Description              | Key switch input.<br>ON with pushbutton disabled.<br>For key switch: ON = pushbutton disabled, OFF = pushbutton enabled. |
|             | Standby status           |  OFF                                   |
|             | If status is not correct | A. Check if the button / key switch is activated / stuck.<br>B. Check the connections between the board and the device.  |

|              |                          |   |
|--------------|--------------------------|---|
| <b>P10.1</b> | Label                    | IN3   |
|              | Description              | Not used  |
|              | Standby status           |  OFF |
|              | If status is not correct | A. Check the connections on the board.  |

## 16.02. Outputs

|             |                          |   |
|-------------|--------------------------|---|
| <b>P2.4</b> | Label                    | ELT-LCK   |
|             | Description              | Command for the landing door ELECTRIC-LOCK.<br>ON with car at floor and when the control panel unlocks the door.  |
|             | Standby status           |  OFF   |
|             | If status is not correct | A. Look for any short-circuit outside the control panel.<br>B. Look for any short-circuit inside the control panel.<br>C. Check the connections on the board. |

|             |                          |   |
|-------------|--------------------------|---|
| <b>P6.1</b> | Label                    | OPEN  |
|             | Description              | Command for the landing door operator - OPEN.   |
|             | Standby status           |  SPENTO  |
|             | If status is not correct | A. Look for any short-circuit outside the control panel.<br>B. Look for any short-circuit inside the control panel.<br>C. Check the connections on the board. |


|             |                          |   |
|-------------|--------------------------|---|
| <b>P6.2</b> | Label                    | CLOSE   |
|             | Description              | Command for the landing door operator - CLOSE.  |
|             | Standby status           |  OFF   |
|             | If status is not correct | <ul style="list-style-type: none"> <li>A. Look for any short-circuit outside the control panel.</li> <li>B. Look for any short-circuit inside the control panel.</li> <li>C. Check the connections on the board.</li> </ul> |

|             |                          |   |
|-------------|--------------------------|---|
| <b>P8.2</b> | Label                    | OUT1  |
|             | Description              | Call button light.<br>ON with button pressed.   |
|             | Standby status           |  OFF   |
|             | If status is not correct | <ul style="list-style-type: none"> <li>A. Look for any short-circuit outside the control panel.</li> <li>B. Look for any short-circuit inside the control panel.</li> <li>C. Check the connections between the board and the button.</li> </ul> |

|             |                          |   |
|-------------|--------------------------|---|
| <b>P9.2</b> | Label                    | OUT2  |
|             | Description              | Car at the floor light.<br>ON with car at floor.  |
|             | Standby status           |  OFF  |
|             | If status is not correct | <ul style="list-style-type: none"> <li>A. Look for any short-circuit outside the control panel.</li> <li>B. Look for any short-circuit inside the control panel.</li> <li>C. Check the connections between the board and the button.</li> </ul> |

|              |                          |  |
|--------------|--------------------------|--|
| <b>P10.2</b> | Label                    | OUT3   |
|              | Description              | Not used   |
|              | Standby status           |  OFF  |
|              | If status is not correct | <ul style="list-style-type: none"> <li>A. Check the connections on the board.</li> </ul> |

## 17. Cabin / Platform board UDEC.C input / output diagnostic



Before checking the LEDs check that the board is properly connected and powered.

### 17.01. Inputs

|             |                          |  |
|-------------|--------------------------|--|
| <b>P0.5</b> | Label                    | 24VIN  |
|             | Description              | 24V DC input voltage supply  |
|             | Standby status           |  ON |
|             | If status is not correct | A. Check the output 24VC on the main board UDEC.M.<br>B. Check the board wirings.      |

|              |                          |  |
|--------------|--------------------------|--|
| <b>P70.3</b> | Label                    | KEY  |
|              | Description              | Key switch for COP disabling.<br>ON with COP disabled.   |
|              | Standby status           |  OFF  |
|              | If status is not correct | A. Check if the key switch is activated / stuck.<br>B. Check the connections between the board and the key switch.<br>C. Check the status of output 24V. |

|                  |                          |  |
|------------------|--------------------------|--|
| <b>P70.4...8</b> | Label                    | PC0...PC04   |
|                  | Description              | Call pushbutton input.<br>ON with button pressed.  |
|                  | Standby status           |  OFF  |
|                  | If status is not correct | A. Check if the button is pressed / stuck.<br>B. Check the connections between the board and the button.<br>C. Check the status of output 24V. |

|                        |                          |   |
|------------------------|--------------------------|---|
| <b>P70.9</b>           | Label                    | REOPEN  |
|                        | Description              | Door reopen pushbutton input.<br>ON with button pressed.  |
|                        | Standby status           |  OFF   |
|                        | If status is not correct | <ul style="list-style-type: none"> <li>A. Check if the button is pressed / stuck.</li> <li>B. Check the connections between the board and the button.</li> <li>C. Check the status of output 24V.</li> </ul>                    |
| <b>P71.3...10</b>      | Label                    | PC6...PC13  |
|                        | Description              | Call pushbutton input.<br>ON with button pressed.   |
|                        | Standby status           |  OFF   |
|                        | If status is not correct | <ul style="list-style-type: none"> <li>A. Check if the button is pressed / stuck.</li> <li>B. Check the connections between the board and the button.</li> <li>C. Check the status of output 24V.</li> </ul>                    |
| <b>P60.2</b>           | Label                    | NUT   |
|                        | Description              | Car safety chain - Nut sensor   |
|                        | Standby status           |  ON   |
|                        | If status is not correct | <ul style="list-style-type: none"> <li>A. Check the status of input S3-PIT on the main board UDEC.M.</li> <li>B. Check the safety switch SQ-MAD.</li> <li>C. Check the connections between the board and the switch.</li> </ul> |
| <b>P61.2</b>           | Label                    | STOP  |
|                        | Description              | Car safety chain - COP emergency stop   |
|                        | Standby status           |  ON  |
|                        | If status is not correct | <ul style="list-style-type: none"> <li>A. Check the status of input NUT.</li> <li>B. Check the emergency stop button SB-PEC.</li> <li>C. Check the connections between the board and the button.</li> </ul>                     |
| <b>P62.2<br/>P63.2</b> | Label                    | PER1 – PER2   |
|                        | Description              | Car safety chain - Perimeter sensors  |
|                        | Standby status           |  ON  |
|                        | If status is not correct | <ul style="list-style-type: none"> <li>A. Check the status of input STOP.</li> <li>B. Check the safety perimeter switches SQ-PER1..4.</li> <li>C. Check the connections between the board and the switches.</li> </ul>          |
| <b>P64.2</b>           | Label                    | PANEL   |
|                        | Description              | Car safety chain - Inspection panel   |
|                        | Standby status           |  ON  |
|                        | If status is not correct | <ul style="list-style-type: none"> <li>A. Check the status of input PER2.</li> <li>B. Check the inspection panel contact SQ-COP.</li> <li>C. Check the connections between the board and the contact.</li> </ul>                |

|                              |                          |  |
|------------------------------|--------------------------|--|
| <b>P65.2</b><br><b>P66.2</b> | Label                    | EDGE   |
|                              | Description              | Car safety chain - COP edge  |
|                              | Standby status           |  ON   |
|                              | If status is not correct | A. Check the status of input PANEL.<br>B. Check the COP edge switches SQ-BOR1 / 2.<br>C. Check the connections between the board and the switches. |

|              |                          |   |
|--------------|--------------------------|---|
| <b>P64.4</b> | Label                    | IN1   |
|              | Description              | Not used  |
|              | Standby status           |  OFF |
|              | If status is not correct | A. Check the connections on the board.  |

|                              |                          |   |
|------------------------------|--------------------------|---|
| <b>P65.4</b><br><b>P66.4</b> | Label                    | IN2   |
|                              | Description              | Not used  |
|                              | Standby status           |  OFF |
|                              | If status is not correct | A. Check the connections on the board.  |

|              |                          |  |
|--------------|--------------------------|--|
| <b>P36.2</b> | Label                    | PREL3  |
|              | Description              | Not used   |
|              | Standby status           |  ON (bridged) |
|              | If status is not correct | A. Check the connections on the board.   |

|              |                          |   |
|--------------|--------------------------|---|
| <b>P37.4</b> | Label                    | OVL   |
|              | Description              | Overload switch input.  |
|              | Standby status           |  ON  |
|              | If status is not correct | A. Check the platform load.<br>B. Check the status of 24VB.<br>C. Check the connections between the control panel and the switch SQ-OVL (DomoFlex) or the weighing unit SP-CAB (IconLift).<br>D. Check if the weighting unit is working properly (specific manual). |

|              |                          |   |
|--------------|--------------------------|---|
| <b>P20.8</b> | Label                    | IR  |
|              | Description              | Position Reed input - IR (zero)   |
|              | Standby status           |  ON  |
|              | If status is not correct | A. Check the alignment between the sensor and the magnet.<br>B. Check the connections between the board and the sensor.<br>C. Check the status of output 24V. |

|              |                          |   |
|--------------|--------------------------|---|
| <b>P20.7</b> | Label                    | IP  |
|              | Description              | Not used  |
|              | Standby status           |  OFF |
|              | If status is not correct | A. Check the connections on the board.  |

|              |                          |   |
|--------------|--------------------------|---|
| <b>P20.6</b> | Label                    | IS  |
|              | Description              | Position Reed input - IS (up direction)   |
|              | Standby status           |  OFF   |
|              | If status is not correct | A. Check the alignment between the sensor and the magnet.<br>B. Check the connections between the board and the sensor.<br>C. Check the status of output 24V. |

|              |                          |   |
|--------------|--------------------------|---|
| <b>P20.5</b> | Label                    | ID  |
|              | Description              | Position Reed input - IS (down direction)   |
|              | Standby status           |  OFF   |
|              | If status is not correct | A. Check the alignment between the sensor and the magnet.<br>B. Check the connections between the board and the sensor.<br>C. Check the status of output 24V. |

## 17.02. Outputs

|  |                          |  |
|--|--------------------------|--|
| <b>P70.11</b><br><b>P71.11</b><br><b>P81.1</b> | Label                    | 24V  |
|  | Description              | 24V DC auxiliary output  |
|  | Standby status           |  ON                               |
|  | If status is not correct | A. Look for any short-circuit on the cable / devices connected to the board.<br>B. Check the status of output 24VIN. |

|              |                          |  |
|--------------|--------------------------|--|
| <b>P25.1</b> | Label                    | ELT-LCK  |
|              | Description              | Enable for the ELECTRIC-LOCK of the landing doors.<br>ON during the unlock of the landing door.  |
|              | Standby status           |  OFF  |
|              | If status is not correct | A. Look for any short-circuit on the cable connected to P25.<br>B. Check the status of input 24VIN.<br>C. Check the communication status on the main board UDEC.M. |

|              |                          |   |
|--------------|--------------------------|---|
| <b>P25.4</b> | Label                    | ELS   |
|              | Description              | Not used  |
|              | Standby status           |  OFF |
|              | If status is not correct | A. Check the connections on the board.  |

|              |                          |   |
|--------------|--------------------------|---|
| <b>P67.1</b> | Label                    | HL-FT   |
|              | Description              | Not used  |
|              | Standby status           |  OFF |
|              | If status is not correct | A. Check the connections on the board.  |

|            |                          |   |
|------------|--------------------------|---|
| <b>P12</b> | Label                    | LIGHT   |
|            | Description              | Supply for the car lights (230V AC).<br>ON during the movement or in error state.   |
|            | Standby status           |  OFF   |
|            | If status is not correct | A. Check the inputs status of UDEC.M starting from the safety chain.<br>B. Check the status of 24V.<br>C. Check the status of QF-4 in the main control panel. |

|  |                          |  |
|--|--------------------------|--|
| <b>P32.6</b><br><b>P35.6</b><br><b>P38.6</b> | Label                    | 24VO   |
|  | Description              | Supply for the car lights (24V DC).<br>ON during the movement or in error state or during a power failure. |
|  | Standby status           |  OFF                      |
|  | If status is not correct | A. Check the inputs status of UDEC.M starting from the safety chain.<br>B. Check the status of 24V.        |

|  |                          |   |
|--|--------------------------|---|
| <b>P31.2</b><br><b>P34.2</b><br><b>P37.2</b> | Label                    | OPEN1..3  |
|  | Description              | Not used  |
|  | Standby status           |  OFF |
|  | If status is not correct | A. Check the connections on the board.  |

|  |                          |   |
|--|--------------------------|---|
| <b>P32.2</b><br><b>P35.2</b><br><b>P38.2</b> | Label                    | CLOSE1..3   |
|  | Description              | Not used  |
|  | Standby status           |  OFF |
|  | If status is not correct | A. Check the connections on the board.  |

## 18. Error codes and troubleshooting

The error codes are divided in families. In order of error severity:

### ERROR CODES

ERR\_Oxxx Related to UDEC.M firmware.

ERR\_Axxx Related to UDEC.M board hardware.

ERR\_Bxxx Related to the main control panel / main components / electric safeties.

ERR\_Cxxx Related to the car / platform.

ERR\_Dxxx Related to the door boards UDEC.D.

### SCREEN TEXT LEGEND

X = Specific kind of error.

n = Number of UDEC.D board.

... = Label assigned to the service (ex. -1C, 3, B, etc.).

### RESET / SOFT RESET / LOG COLUMNS

Reset YES means that a reset from the control panel is necessary to restore the normal operations (see §10)

Soft reset YES means that is possible to reset the error from the COPs on the platform (see §10)

Log YES means that the error occurrence is stored in the error log (see §10)



In the following pages, the error diagnostics refers always to the IOs of the main board UDEC.M when no board name is reported.

| SCREEN [ENG]        | Description   | Action #1  | Action #2 | Action #3 | Reset      | Soft reset | Log        |
|---------------------|---|--|-----------|-----------|------------|------------|------------|
| ERR_0000<br>FW X    | Firmware error.<br>X = 0...4: hard error.<br>X = 6...10: initialization error.<br>X = 11...14: application error.<br>X = 15...16: peripheral error.<br>X = 17...18: log error.<br>X = 19...20: parameter error. | If the error occurs frequently take note of the error history and report to LiftingItalia.<br>The board reboots automatically. | -         | -         |            | <b>NO</b>  | <b>NO</b>  |
| ERR_A000<br>24V     | Undervoltage error at input of UDEC.M.  | See IO diagnostic of input 24VIN.  | -         | -         | <b>YES</b> | <b>YES</b> | <b>YES</b> |
| ERR_A001<br>24V-AUX | Short circuit / heavy overload detected on auxiliary 24V.   | See IO diagnostic of output 24VA.  | -         | -         | <b>YES</b> | <b>YES</b> | <b>YES</b> |

| SCREEN [ENG]         | Description   | Action #1   | Action #2  | Action #3          | Reset | Soft reset | Log |
|----------------------|---|---|--|--------------------|-------|------------|-----|
| ERR_A002<br>24V-MOV  | Short circuit / heavy overload detected on motion 24V.  | See IO diagnostic of output 24VM.   | -  | -                  | YES   | YES        | YES |
| ERR_A003<br>24V-VAN  | Short circuit / heavy overload detected on shaft 24V.   | See IO diagnostic of output 24VV.   | -  | -                  | YES   | YES        | YES |
| ERR_A004<br>24V-CAB  | Short circuit / heavy overload detected on cabin 24V.   | See IO diagnostic of output 24VC.   | -  | -                  | YES   | YES        | YES |
| ERR_A010<br>CAN FW X | CAN firmware error.<br>X = 0: RX buffer overrun.<br>X = 1: TX buffer overrun.                                 | If the error occurs frequently take note of the error history and report to LiftingItalia.<br>The board recovers automatically. | -  | -                  | NO    | NO         | YES |
| ERR_A020<br>CAN HL X | CAN hardware error.<br>X = specific error.  | If the error occurs frequently take note of the error history and report to LiftingItalia.<br>The board recovers automatically. | -  | -                  | NO    | NO         | YES |
| ERR_A030<br>RelXClos | UDEC.M internal relay glued in closed position.<br>X = 1: feedback OTR-1 / 2.<br>X = 2: feedback DNW and BRK. | If there are errors related to 24V solve them and make a reset.   | Check for possible errors in wirings of P22, P23, P24, P25. Disconnect P22, P23, P24, P25 and check if the error occurs again. | Replace the board. | YES   | NO         | YES |
| ERR_A031<br>RelXOpen | UDEC.M internal relay glued in open position.<br>X = 1: feedback OTR-1 / 2.<br>X = 2: feedback DNW and BRK.   | If there are errors related to 24V solve them and make a reset.   | Replace the board.   | -                  | YES   | NO         | YES |
| ERR_A040<br>RedBotto | Redundancy checks on safe bottom inputs failed.   | See IO diagnostic for LEDs BOTTOM and IN-4. The two inputs must switch in synchro.  | Test the single inputs with a piece of wire connected to 24V.  | Replace the board. | YES   | NO         | YES |
| ERR_B010<br>ContClos | Safety contactor KG-SEC1 / 2 glued in closed position.  | See IO diagnostic of input FBK-C.   | Replace both contactors.   | -                  | YES   | NO         | YES |
| ERR_B011<br>ContOpen | Safety contactor KG-SEC1 / 2 glued in open position.  | See IO diagnostic of input FBK-C.   | Replace both contactors.   | -                  | YES   | NO         | YES |

# DomoFlex 2<sup>®</sup> and IconLift<sup>®</sup>

## U.D.E.C. - INSTALLATION AND DIAGNOSTICS

| SCREEN [ENG]         | Description  | Action #1                                     | Action #2   | Action #3          | Reset | Soft reset | Log |
|----------------------|--|---|---|--------------------|-------|------------|-----|
| ERR_B012<br>EmgClos  | Emergency operation relay 1 / 2 glued in closed position.                              | See IO diagnostic of input FBK-EM.            | Replace UDEC.P board.   | -                  | YES   | NO         | YES |
| ERR_B013<br>EmgOpen  | Emergency operation relay 1 / 2 glued in open position.                                | See IO diagnostic of input FBK-EM.            | Replace UDEC.P board.   | -                  | YES   | NO         | YES |
| ERR_B021<br>PositioX | Anomaly detected on the position sensors (see §8).<br>X = 1: incorrect sequence.       | See IO diagnostic of inputs IR, ID, IS.       | -   | -                  | YES   | NO         | YES |
| ERR_B030<br>Inverter | Inverter fault   | See IO diagnostic of input INV.               | Take note of the error code shown on the inverter display and contact LiftingItalia.      | -                  | YES   | YES        | YES |
| ERR_B040<br>SafChain | Anomaly detected on the safety chain inputs of UDEC.M (ex. hole in the series).        | See IO diagnostic from input S1-IN to S8-END. | Check the wirings looking for short circuits between the safety chain and other circuits. | Replace the board. | YES   | NO         | YES |
| ERR_B041<br>QF-SER   | Magnetic circuit breaker QF-SER open.  | See IO diagnostic of input S1-IN.             | Check for short circuits on the safety chain.   | -                  | YES   | NO         | YES |
| ERR_B042<br>Overtrav | Overtravel switch open (SQ-EXC1 / 2).  | See IO diagnostic of input S2-OVT.            | -   | -                  | YES   | NO         | YES |
| ERR_B043<br>Belts    | Pit's safety contacts open (pit emergency stop SB-PEF or safe pit contact SQ-FF).      | See IO diagnostic of input S3-BLT.            | -   | -                  | YES   | NO         | YES |
| ERR_B044<br>SafCha 4 | Movement interruption due to safety chain opening (S4-CAB - cabin safeties).           | See IO diagnostic of input S4-CAR.            | -   | -                  | NO    | NO         | YES |
| ERR_B045<br>SafCha 5 | Movement interruption due to safety chain opening (S5-APP – landing door preliminary). | See IO diagnostic of input S5-APP.            | -   | -                  | NO    | NO         | YES |
| ERR_B046<br>SafCha 6 | Movement interruption due to safety chain opening (S6-CPC – car door preliminary).     | See IO diagnostic of input S6-CPC.            | -   | -                  | NO    | NO         | YES |
| ERR_B047<br>SafCha 7 | Movement interruption due to safety chain opening (S7-BLK – landing door locks).       | See IO diagnostic of input S7-BLK.            | -   | -                  | NO    | NO         | YES |

| SCREEN<br>[ENG]        | Description  | Action #1   | Action #2   | Action #3  | Reset | Soft<br>reset | Log |
|------------------------|--|---|---|--|-------|---------------|-----|
| ERR_B050<br>t-traveX   | Travel timeout (travel time + 5s).<br>X = D: downward.<br>X = A: upward.   | Check that the travel parameter is properly set (see §20).  | Check the speed of the cabin and that its movement is free from obstacles.      | Check the connections between the control panel and the inverter.              | YES   | NO            | YES |
| ERR_B060<br>Blackout   | Blackout – absence of 230V AC supply.  | See IO diagnostic of input GRID-OK.   | -   | -  | NO    | NO            | NO  |
| ERR_B061<br>Battery    | Batteries not connected or discharged.   | See IO diagnostic of input BAT-KO   | -   | -  | NO    | NO            | NO  |
| ERR_B070<br>PitAcces   | Pit access detected either by the unlock of the lowest landing door or safety chain S3-PIT.  | See IO diagnostic of output HL-FF and S3-PIT.   | -   | -  | YES   | NO            | YES |
| ERR_C005<br>R24V CAB   | Exceeded the maximum number of automatic resets for door board UDEC.C – 24V faults.  | Check for short circuits / overload of the devices connected to the car board.  | Check the connections of the car board to the control panel.                    | -  | YES   | YES           | YES |
| ERR_C010<br>CAN CAB.   | Exceeded the maximum number of automatic resets for door board UDEC.C – CAN faults.  | Take note of the error history and report to Liftingitalia if the error occurs frequently.                                      | Check the connections of the car board to the control panel.                    | Check for short circuits / overload of the devices connected to the car board. | YES   | YES           | YES |
| ERR_C021<br>ScrewSen   | Screw lifted sensor engaged (SQ-VIT).  | See IO diagnostic of input SCREW.   | -   | -  | YES   | NO            | YES |
| ERR_C030<br>Overload   | Overload detected by the weighting unit or the overload switch.  | See IO diagnostic of input OVL on UDEC.C.   | -   | -  | NO    | NO            | NO  |
| “ERR_C050<br>SWX CAB”  | Status word notification of door board UDEC.C.<br>X = 0: board reboot.<br>X = 1: undervoltage.<br>X = 2: overcurrent on electric lock output.<br>X = 3: short circuit on generic 24V output.<br>X = 4...13: CAN error. | Take note of the error history and report to Liftingitalia if the error occurs frequently.<br>The board recovers automatically. | -   | -  | NO    | NO            | YES |
| ERR_Dn05<br>R24V “...” | Exceeded the maximum number of automatic resets for door board UDEC.D – 24V faults.  | Check for short circuits / overload of the devices connected to the door board.   | Check the connections of the door board to the shaft backbone cable.            | -  | YES   | YES           | YES |
| ERR_Dn10<br>CAND “...” | Door board UDEC.D not alive on CAN bus.  | Check the connections of the door board to the shaft backbone cable.<br>The board recovers automatically.                       | Check for short circuits / overload of the devices connected to the door board. | -  | NO    | NO            | YES |

# DomoFlex 2<sup>®</sup> and IconLift<sup>®</sup>

## U.D.E.C. - INSTALLATION AND DIAGNOSTICS

| SCREEN<br>[ENG]        | Description   | Action #1   | Action #2  | Action #3   | Reset | Soft<br>reset | Log |
|------------------------|---|---|--|---|-------|---------------|-----|
| ERR_Dn11<br>RCAN "..." | Exceeded the maximum number of automatic resets for door board UDEC.D – CAN faults.   | Take note of the error history and report to LiftingItalia if the error occurs frequently.                                      | Check the connections of the door board to the shaft backbone cable. | Check for short circuits / overload of the devices connected to the door board. | YES   | YES           | YES |
| ERR_Dn20<br>SWX "..."  | Status word notification of door board UDEC.D.<br>X = 0: board reboot.<br>X = 1: undervoltage.<br>X = 2: overcurrent on electric lock output.<br>X = 3...12: CAN error. | Take note of the error history and report to LiftingItalia if the error occurs frequently.<br>The board recovers automatically. | -  | -   | NO    | NO            | YES |

## 19. HMI menu and parameters

| LEVEL_1              | LEVEL_2  | LEVEL_3  | DESCRIPTION   |
|----------------------|----------|----------|---|
| <b>OperMode</b>      |          |          |   |
|                      | Normal   |          | ▶ Set normal mode (§10).  |
|                      | Mainten. |          | ▶ Set maintenance mode (§10).   |
|                      | Commiss. |          |   |
|                      |          | Overtrav | ▶ Overtravel commissioning (§10).   |
|                      |          | BeltSafe | ▶ Belts safe commissioning (§10).   |
| <b>Paramete</b>      |          |          |   |
|                      | General  |          | ▶ General parameters.   |
|                      | Machine  |          | ▶ Machine parameters.   |
|                      | Landings |          | ▶ Landing doors parameters.   |
|                      | Cabin    |          | ▶ Cabin parameters.   |
|                      | CarDoors |          | ▶ Car doors parameters.   |
| <b>Diagnos</b>       |          |          |   |
|                      | ErrorLog |          | ▶ General parameters.   |
|                      |          | Read     | ▶ The display shows three screens: date&time of error, error code and the system dump. Use the arrows to scroll the log (max 10 records). |
|                      |          | Clear    | ▶ Clear the error log.  |
|                      | UDEC.M   |          |   |
|                      |          | FW Vers. | ▶ Shows firmware version.   |
|                      |          | CAN stat | ▶ Shows CAN-bus statistics.   |
|                      | UDEC.C   |          |   |
|                      | UDEC.D   |          |   |
| <b>Date&amp;Time</b> |          |          | ▶ Change date and time.   |
| <b>Login</b>         |          |          | ▶ Change user   |

|   |  |
|---|--|
|  | The changes to these parameters need a board restart (turn off - turn on) to be effective. |
|---|--|

**19.01. Menu - Section 'Parameter' Details**

| CAT     | VIRTUAL ADRESS | DESCRIPTION                | Min  | Max   | Default |
|---------|----------------|----------------------------|------|-------|---------|
| General | A000           | MachineType                | 0    | 4     | 0       |
|         | A001           | Year                       | 2015 | 2030  | 2022    |
|         | A002           | OdV                        | 1    | 2000  | 1000    |
|         | A003           | CustomerID                 | 0    | 65535 | 0       |
|         | A004           | Language                   | 0    | 1     | 0       |
|         | A005           | FormatDate                 | 0    | 1     | 0       |
|         | A006           | User                       | 0    | 2     | 0       |
|         | A007           | N_UDEC_D                   | 2    | 16    | 2       |
|         | A008           | Diagnostic Level           | 0    | 3     | 0       |
| Machine | B000           | Travel                     | 500  | 20000 | 1800    |
|         | B001           | Pit                        | 0    | 5000  | 150     |
|         | B002           | Head                       | 0    | 5000  | 2500    |
|         | B003           | Nservices                  | 2    | 16    | 2       |
|         | B004           | Nstops                     | 2    | 16    | 2       |
|         | B005           | Speed                      | 1    | 300   | 150     |
|         | B006           | Floor operation            | 0    | 1     | 1       |
|         | B007           | Cabin operation            | 0    | 1     | 0       |
|         | B008           | OperationRemote controls   | 0    | 1     | 0       |
|         | B009           | Parking stop               | 0    | 16    | 0       |
|         | B00A           | Parking Time               | 1    | 255   | 15      |
|         | B00B           | Fire Operation Service     | 0    | 16    | 0       |
|         | B00C           | A3 operation               | 0    | 1     | 0       |
|         | B00D           | PitAccess Control          | 0    | 1     | 1       |
|         | B00E           | Header Access Control      | 0    | 1     | 0       |
|         | B00F           | Compartment Access Control | 0    | 1     | 0       |
|         | B010           | DescentBlackoutInHighSpeed | 0    | 1     | 0       |
|         | B011           | DescentBlackoutP0          | 0    | 1     | 0       |
|         | B012           | Dorsal Compartment         | 0    | 2     | 0       |
|         | B013           | MagnetsSlowdown            | 0    | 65535 | 65535   |
|         | B014           | ThresholdThermistorsH      | 0    | 65535 | 31100   |
|         | B015           | ThresholdThermistorsL      | 0    | 65535 | 28500   |
|         | B016           | ContactTypeOverload        | 0    | 1     | 1       |
|         | B017           | LowSpeed Timeout           | 0    | 255   | 10      |
|         | B018           | Three-phase power supply   | 0    | 1     | 0       |
|         | B019           | FireOperation DoorClose    | 0    | 1     | 0       |

| CAT         | VIRTUAL ADRESS | DESCRIPTION             | Min | Max   | Default |
|-------------|----------------|-------------------------|-----|-------|---------|
| Landings[0] | D000           | Label                   | 0   | 65535 | 8240    |
|             | D001           | Interfloor              | 0   | 65535 | 3000    |
|             | D002           | Level                   | 0   | 15    | 0       |
|             | D003           | Side                    | 0   | 3     | 0       |
|             | D004           | Multiple Service        | 0   | 1     | 0       |
|             | D005           | DoorType                | 0   | 3     | 0       |
|             | D006           | TypeUnlock              | 0   | 5     | 0       |
|             | D007           | ContactTypePresent      | 0   | 1     | 0       |
|             | D008           | OperatorType            | 0   | 6     | 0       |
|             | D009           | OpeningCommand Duration | 0   | 255   | 15      |
|             | D00A           | ClosureCommand Duration | 0   | 255   | 15      |
|             | D00B           | idxDorsal               | 0   | 15    | 0       |
|             | D00C           | ParkingDoorsOpen        | 0   | 1     | 0       |
|             | D00D           | Buzzer                  | 0   | 1     | 1       |
|             | D00E           | IN2 function            | 0   | 6     | 0       |
|             | D00F           | IN3 function            | 0   | 6     | 0       |
| Landings[1] | D100           | Label                   | 0   | 65535 | 8241    |
|             | D101           | Interfloor              | 0   | 65535 | 3000    |
|             | D102           | Level                   | 0   | 15    | 1       |
|             | D103           | Side                    | 0   | 3     | 0       |
|             | D104           | Multiple Service        | 0   | 1     | 0       |
|             | D105           | DoorType                | 0   | 3     | 0       |
|             | D106           | TypeUnlock              | 0   | 5     | 0       |
|             | D107           | ContactTypePresent      | 0   | 1     | 0       |
|             | D108           | OperatorType            | 0   | 6     | 0       |
|             | D109           | OpeningCommand Duration | 0   | 255   | 15      |
|             | D10A           | ClosureCommand Duration | 0   | 255   | 15      |
|             | D10B           | idxDorsal               | 0   | 15    | 1       |
|             | D10C           | ParkingDoorsOpen        | 0   | 1     | 0       |
|             | D10D           | Buzzer                  | 0   | 1     | 1       |
|             | D10E           | IN2 function            | 0   | 6     | 0       |
|             | D10F           | IN3 function            | 0   | 6     | 0       |
| Landings[2] | -              | Label                   | 0   | 65535 | 8242    |
|             | -              | Interfloor              | 0   | 65535 | 3000    |
|             | -              | Level                   | 0   | 15    | 2       |
|             | -              | Side                    | 0   | 3     | 0       |
|             | -              | Multiple Service        | 0   | 1     | 0       |

| CAT         | VIRTUAL ADRESS | DESCRIPTION             | Min | Max   | Default |
|-------------|----------------|-------------------------|-----|-------|---------|
|             | –              | DoorType                | 0   | 3     | 0       |
|             | –              | TypeUnlock              | 0   | 5     | 0       |
|             | –              | ContactTypePresent      | 0   | 1     | 0       |
|             | –              | OperatorType            | 0   | 6     | 0       |
|             | –              | OpeningCommand Duration | 0   | 255   | 15      |
|             | –              | ClosureCommand Duration | 0   | 255   | 15      |
|             | –              | idxDorsal               | 0   | 15    | 2       |
|             | –              | ParkingDoorsOpen        | 0   | 1     | 0       |
|             | –              | Buzzer                  | 0   | 1     | 1       |
|             | –              | IN2 function            | 0   | 6     | 0       |
|             | –              | IN3 function            | 0   | 6     | 0       |
| Landings[3] | –              | Label                   | 0   | 65535 | 8243    |
|             | –              | Interfloor              | 0   | 65535 | 3000    |
|             | –              | Level                   | 0   | 15    | 3       |
|             | –              | Side                    | 0   | 3     | 0       |
|             | –              | Multiple Service        | 0   | 1     | 0       |
|             | –              | DoorType                | 0   | 3     | 0       |
|             | –              | TypeUnlock              | 0   | 5     | 0       |
|             | –              | ContactTypePresent      | 0   | 1     | 0       |
|             | –              | OperatorType            | 0   | 6     | 0       |
|             | –              | OpeningCommand Duration | 0   | 255   | 15      |
|             | –              | ClosureCommand Duration | 0   | 255   | 15      |
|             | –              | idxDorsal               | 0   | 15    | 3       |
|             | –              | ParkingDoorsOpen        | 0   | 1     | 0       |
|             | –              | Buzzer                  | 0   | 1     | 1       |
|             | –              | IN2 function            | 0   | 6     | 0       |
|             | –              | IN3 function            | 0   | 6     | 0       |
| Landings[4] | –              | Label                   | 0   | 65535 | 8244    |
|             | –              | Interfloor              | 0   | 65535 | 3000    |
|             | –              | Level                   | 0   | 15    | 4       |
|             | –              | Side                    | 0   | 3     | 0       |
|             | –              | Multiple Service        | 0   | 1     | 0       |
|             | –              | DoorType                | 0   | 3     | 0       |
|             | –              | TypeUnlock              | 0   | 5     | 0       |
|             | –              | ContactTypePresent      | 0   | 1     | 0       |
|             | –              | OperatorType            | 0   | 6     | 0       |
|             | –              | OpeningCommand Duration | 0   | 255   | 15      |
|             | –              | ClosureCommand Duration | 0   | 255   | 15      |

| CAT         | VIRTUAL ADRESS | DESCRIPTION             | Min | Max   | Default |
|-------------|----------------|-------------------------|-----|-------|---------|
| Landings[5] | –              | idxDorsal               | 0   | 15    | 4       |
|             | –              | ParkingDoorsOpen        | 0   | 1     | 0       |
|             | –              | Buzzer                  | 0   | 1     | 1       |
|             | –              | IN2 function            | 0   | 6     | 0       |
|             | –              | IN3 function            | 0   | 6     | 0       |
| Landings[8] | –              | Label                   | 0   | 65535 | 8245    |
|             | –              | Interfloor              | 0   | 65535 | 3000    |
|             | –              | Level                   | 0   | 15    | 5       |
|             | –              | Side                    | 0   | 3     | 0       |
|             | –              | Multiple Service        | 0   | 1     | 0       |
|             | –              | DoorType                | 0   | 3     | 0       |
|             | –              | TypeUnlock              | 0   | 5     | 0       |
|             | –              | ContactTypePresent      | 0   | 1     | 0       |
|             | –              | OperatorType            | 0   | 6     | 0       |
|             | –              | OpeningCommand Duration | 0   | 255   | 15      |
|             | –              | ClosureCommand Duration | 0   | 255   | 15      |
|             | –              | idxDorsal               | 0   | 15    | 5       |
|             | –              | ParkingDoorsOpen        | 0   | 1     | 0       |
|             | –              | Buzzer                  | 0   | 1     | 1       |
|             | –              | IN2 function            | 0   | 6     | 0       |
|             | –              | IN3 function            | 0   | 6     | 0       |

# DomoFlex 2® and IconLift®

U.D.E.C. - INSTALLATION AND DIAGNOSTICS

| CAT         | VIRTUAL ADRESS | DESCRIPTION             | Min | Max   | Default |
|-------------|----------------|-------------------------|-----|-------|---------|
| Landings[7] | –              | Label                   | 0   | 65535 | 8247    |
|             | –              | Interfloor              | 0   | 65535 | 3000    |
|             | –              | Level                   | 0   | 15    | 7       |
|             | –              | Side                    | 0   | 3     | 0       |
|             | –              | Multiple Service        | 0   | 1     | 0       |
|             | –              | DoorType                | 0   | 3     | 0       |
|             | –              | TypeUnlock              | 0   | 5     | 0       |
|             | –              | ContactTypePresent      | 0   | 1     | 0       |
|             | –              | OperatorType            | 0   | 6     | 0       |
|             | –              | OpeningCommand Duration | 0   | 255   | 15      |
|             | –              | ClosureCommand Duration | 0   | 255   | 15      |
|             | –              | idxDorsal               | 0   | 15    | 7       |
|             | –              | ParkingDoorsOpen        | 0   | 1     | 0       |
|             | –              | Buzzer                  | 0   | 1     | 1       |
|             | –              | IN2 function            | 0   | 6     | 0       |
|             | –              | IN3 function            | 0   | 6     | 0       |
| Landings[8] | –              | Label                   | 0   | 65535 | 8248    |
|             | –              | Interfloor              | 0   | 65535 | 3000    |
|             | –              | Level                   | 0   | 15    | 8       |
|             | –              | Side                    | 0   | 3     | 0       |
|             | –              | Multiple Service        | 0   | 1     | 0       |
|             | –              | DoorType                | 0   | 3     | 0       |
|             | –              | TypeUnlock              | 0   | 5     | 0       |
|             | –              | ContactTypePresent      | 0   | 1     | 0       |
|             | –              | OperatorType            | 0   | 6     | 0       |
|             | –              | OpeningCommand Duration | 0   | 255   | 15      |
|             | –              | ClosureCommand Duration | 0   | 255   | 15      |
|             | –              | idxDorsal               | 0   | 15    | 8       |
|             | –              | ParkingDoorsOpen        | 0   | 1     | 0       |
|             | –              | Buzzer                  | 0   | 1     | 1       |
|             | –              | IN2 function            | 0   | 6     | 0       |
|             | –              | IN3 function            | 0   | 6     | 0       |
| Landings[9] | –              | Label                   | 0   | 65535 | 8249    |
|             | –              | Interfloor              | 0   | 65535 | 3000    |
|             | –              | Level                   | 0   | 15    | 9       |
|             | –              | Side                    | 0   | 3     | 0       |
|             | –              | Multiple Service        | 0   | 1     | 0       |

| CAT          | VIRTUAL ADRESS | DESCRIPTION             | Min | Max   | Default |
|--------------|----------------|-------------------------|-----|-------|---------|
|              | –              | DoorType                | 0   | 3     | 0       |
|              | –              | TypeUnlock              | 0   | 5     | 0       |
|              | –              | ContactTypePresent      | 0   | 1     | 0       |
|              | –              | OperatorType            | 0   | 6     | 0       |
|              | –              | OpeningCommand Duration | 0   | 255   | 15      |
|              | –              | ClosureCommand Duration | 0   | 255   | 15      |
|              | –              | idxDorsal               | 0   | 15    | 9       |
|              | –              | ParkingDoorsOpen        | 0   | 1     | 0       |
|              | –              | Buzzer                  | 0   | 1     | 1       |
|              | –              | IN2 function            | 0   | 6     | 0       |
|              | –              | IN3 function            | 0   | 6     | 0       |
| Landings[10] | –              | Label                   | 0   | 65535 | 8250    |
|              | –              | Interfloor              | 0   | 65535 | 3000    |
|              | –              | Level                   | 0   | 15    | 10      |
|              | –              | Side                    | 0   | 3     | 0       |
|              | –              | Multiple Service        | 0   | 1     | 0       |
|              | –              | DoorType                | 0   | 3     | 0       |
|              | –              | TypeUnlock              | 0   | 5     | 0       |
|              | –              | ContactTypePresent      | 0   | 1     | 0       |
|              | –              | OperatorType            | 0   | 6     | 0       |
|              | –              | OpeningCommand Duration | 0   | 255   | 15      |
|              | –              | ClosureCommand Duration | 0   | 255   | 15      |
|              | –              | idxDorsal               | 0   | 15    | 10      |
|              | –              | ParkingDoorsOpen        | 0   | 1     | 0       |
|              | –              | Buzzer                  | 0   | 1     | 1       |
|              | –              | IN2 function            | 0   | 6     | 0       |
|              | –              | IN3 function            | 0   | 6     | 0       |
| Landings[11] | –              | Label                   | 0   | 65535 | 8251    |
|              | –              | Interfloor              | 0   | 65535 | 3000    |
|              | –              | Level                   | 0   | 15    | 11      |
|              | –              | Side                    | 0   | 3     | 0       |
|              | –              | Multiple Service        | 0   | 1     | 0       |
|              | –              | DoorType                | 0   | 3     | 0       |
|              | –              | TypeUnlock              | 0   | 5     | 0       |
|              | –              | ContactTypePresent      | 0   | 1     | 0       |
|              | –              | OperatorType            | 0   | 6     | 0       |
|              | –              | OpeningCommand Duration | 0   | 255   | 15      |
|              | –              | ClosureCommand Duration | 0   | 255   | 15      |

# DomoFlex 2® and IconLift®

U.D.E.C. - INSTALLATION AND DIAGNOSTICS

| CAT          | VIRTUAL ADRESS | DESCRIPTION             | Min | Max   | Default |
|--------------|----------------|-------------------------|-----|-------|---------|
|              | –              | idxDorsal               | 0   | 15    | 11      |
|              | –              | ParkingDoorsOpen        | 0   | 1     | 0       |
|              | –              | Buzzer                  | 0   | 1     | 1       |
|              | –              | IN2 function            | 0   | 6     | 0       |
|              | –              | IN3 function            | 0   | 6     | 0       |
| Landings[12] | –              | Label                   | 0   | 65535 | 8252    |
|              | –              | Interfloor              | 0   | 65535 | 3000    |
|              | –              | Level                   | 0   | 15    | 12      |
|              | –              | Side                    | 0   | 3     | 0       |
|              | –              | Multiple Service        | 0   | 1     | 0       |
|              | –              | DoorType                | 0   | 3     | 0       |
|              | –              | TypeUnlock              | 0   | 5     | 0       |
|              | –              | ContactTypePresent      | 0   | 1     | 0       |
|              | –              | OperatorType            | 0   | 6     | 0       |
|              | –              | OpeningCommand Duration | 0   | 255   | 15      |
|              | –              | ClosureCommand Duration | 0   | 255   | 15      |
|              | –              | idxDorsal               | 0   | 15    | 12      |
|              | –              | ParkingDoorsOpen        | 0   | 1     | 0       |
|              | –              | Buzzer                  | 0   | 1     | 1       |
|              | –              | IN2 function            | 0   | 6     | 0       |
|              | –              | IN3 function            | 0   | 6     | 0       |
| Landings[13] | –              | Label                   | 0   | 65535 | 8253    |
|              | –              | Interfloor              | 0   | 65535 | 3000    |
|              | –              | Level                   | 0   | 15    | 13      |
|              | –              | Side                    | 0   | 3     | 0       |
|              | –              | Multiple Service        | 0   | 1     | 0       |
|              | –              | DoorType                | 0   | 3     | 0       |
|              | –              | TypeUnlock              | 0   | 5     | 0       |
|              | –              | ContactTypePresent      | 0   | 1     | 0       |
|              | –              | OperatorType            | 0   | 6     | 0       |
|              | –              | OpeningCommand Duration | 0   | 255   | 15      |
|              | –              | ClosureCommand Duration | 0   | 255   | 15      |
|              | –              | idxDorsal               | 0   | 15    | 13      |
|              | –              | ParkingDoorsOpen        | 0   | 1     | 0       |
|              | –              | Buzzer                  | 0   | 1     | 1       |
|              | –              | IN2 function            | 0   | 6     | 0       |
|              | –              | IN3 function            | 0   | 6     | 0       |

| CAT          | VIRTUAL ADRESS | DESCRIPTION             | Min | Max   | Default |
|--------------|----------------|-------------------------|-----|-------|---------|
| Landings[14] | –              | Label                   | 0   | 65535 | 8254    |
|              | –              | Interfloor              | 0   | 65535 | 3000    |
|              | –              | Level                   | 0   | 15    | 14      |
|              | –              | Side                    | 0   | 3     | 0       |
|              | –              | Multiple Service        | 0   | 1     | 0       |
|              | –              | DoorType                | 0   | 3     | 0       |
|              | –              | TypeUnlock              | 0   | 5     | 0       |
|              | –              | ContactTypePresent      | 0   | 1     | 0       |
|              | –              | OperatorType            | 0   | 6     | 0       |
|              | –              | OpeningCommand Duration | 0   | 255   | 15      |
|              | –              | ClosureCommand Duration | 0   | 255   | 15      |
|              | –              | idxDorsal               | 0   | 15    | 14      |
|              | –              | ParkingDoorsOpen        | 0   | 1     | 0       |
|              | –              | Buzzer                  | 0   | 1     | 1       |
| Landings[15] | –              | IN2 function            | 0   | 6     | 0       |
|              | –              | IN3 function            | 0   | 6     | 0       |
|              | –              | Label                   | 0   | 65535 | 8255    |
|              | –              | Interfloor              | 0   | 65535 | 3000    |
|              | –              | Level                   | 0   | 15    | 15      |
|              | –              | Side                    | 0   | 3     | 0       |
|              | –              | Multiple Service        | 0   | 1     | 0       |
|              | –              | DoorType                | 0   | 3     | 0       |
|              | –              | TypeUnlock              | 0   | 5     | 0       |
|              | –              | ContactTypePresent      | 0   | 1     | 0       |
|              | –              | OperatorType            | 0   | 6     | 0       |
|              | –              | OpeningCommand Duration | 0   | 255   | 15      |
|              | –              | ClosureCommand Duration | 0   | 255   | 15      |
|              | –              | idxDorsal               | 0   | 15    | 15      |
| Operators[0] | –              | ParkingDoorsOpen        | 0   | 1     | 0       |
|              | –              | Buzzer                  | 0   | 1     | 1       |
|              | –              | IN2 function            | 0   | 6     | 0       |
|              | –              | Label                   | 0   | 6     | 0       |

# DomoFlex 2® and IconLift®

## U.D.E.C. - INSTALLATION AND DIAGNOSTICS

| CAT          | VIRTUAL ADRESS | DESCRIPTION                            | Min | Max  | Default |
|--------------|----------------|--|-----|------|---------|
| Operators[1] | –              | Door opening speed                     | 3   | 8    | 3       |
|              | –              | Door closing speed                     | 3   | 8    | 3       |
|              | –              | Opening approach deceleration distance | 0   | 1000 | 100     |
|              | –              | Closing approach deceleration distance | 0   | 1000 | 100     |
| Operators[2] | –              | Door opening speed                     | 3   | 8    | 3       |
|              | –              | Door closing speed                     | 3   | 8    | 3       |
|              | –              | Opening approach deceleration distance | 0   | 1000 | 100     |
|              | –              | Closing approach deceleration distance | 0   | 1000 | 100     |
| Operators[3] | –              | Door opening speed                     | 3   | 8    | 3       |
|              | –              | Door closing speed                     | 3   | 8    | 3       |
|              | –              | Opening approach deceleration distance | 0   | 1000 | 100     |
|              | –              | Closing approach deceleration distance | 0   | 1000 | 100     |
| Operators[4] | –              | Door opening speed                     | 3   | 8    | 3       |
|              | –              | Door closing speed                     | 3   | 8    | 3       |
|              | –              | Opening approach deceleration distance | 0   | 1000 | 100     |
|              | –              | Closing approach deceleration distance | 0   | 1000 | 100     |
| Operators[5] | –              | Door opening speed                     | 3   | 8    | 3       |
|              | –              | Door closing speed                     | 3   | 8    | 3       |
|              | –              | Opening approach deceleration distance | 0   | 1000 | 100     |
|              | –              | Closing approach deceleration distance | 0   | 1000 | 100     |
| Operators[8] | –              | Door opening speed                     | 3   | 8    | 3       |
|              | –              | Door closing speed                     | 3   | 8    | 3       |
|              | –              | Opening approach deceleration distance | 0   | 1000 | 100     |
|              | –              | Closing approach deceleration distance | 0   | 1000 | 100     |
| Operators[7] | –              | Door opening speed                     | 3   | 8    | 3       |
|              | –              | Door closing speed                     | 3   | 8    | 3       |
|              | –              | Opening approach deceleration distance | 0   | 1000 | 100     |
|              | –              | Closing approach deceleration distance | 0   | 1000 | 100     |
| Cabin        | C000           | Naccess                                | 1   | 3    | 1       |
|              | C001           | Enable SideB                           | 0   | 1    | 0       |
|              | C002           | Enable SideC                           | 0   | 1    | 0       |
|              | C003           | Enable SideD                           | 0   | 1    | 0       |
|              | C004           | Fan                                    | 0   | 3    | 0       |
|              | C005           | Gong                                   | 0   | 1    | 0       |
|              | C006           | Cabin Light Delay                      | 0   | 255  | 10      |
|              | C007           | P71Function                            | 0   | 7    | 1       |

| CAT         | VIRTUAL ADRESS | DESCRIPTION             | Min | Max   | Default |
|-------------|----------------|-------------------------|-----|-------|---------|
|             | C008           | Buzzer                  | 0   | 1     | 1       |
|             | C009           | ServicesDisabledByKey   | 0   | 65535 | 65535   |
|             | C0A            | CopDisplay              | 0   | 1     | 0       |
| CarDoors[0] | CA00           | DoorType                | 0   | 3     | 3       |
|             | CA01           | OperatorType            | 0   | 4     | 4       |
|             | CA02           | Protection Type         | 0   | 2     | 1       |
|             | CA03           | OpeningCommand Duration | 0   | 255   | 15      |
|             | CA04           | ClosureCommand Duration | 0   | 255   | 15      |
|             | CA05           | ParkingDoorsOpen        | 0   | 1     | 0       |
| CarDoors[1] | –              | DoorType                | 0   | 3     | 3       |
|             | –              | OperatorType            | 0   | 4     | 4       |
|             | –              | Protection Type         | 0   | 2     | 1       |
|             | –              | OpeningCommand Duration | 0   | 255   | 15      |
|             | –              | ClosureCommand Duration | 0   | 255   | 15      |
|             | –              | ParkingDoorsOpen        | 0   | 1     | 0       |
| CarDoors[2] | –              | DoorType                | 0   | 3     | 3       |
|             | –              | OperatorType            | 0   | 4     | 4       |
|             | –              | Protection Type         | 0   | 2     | 1       |
|             | –              | OpeningCommand Duration | 0   | 255   | 15      |
|             | –              | ClosureCommand Duration | 0   | 255   | 15      |
|             | –              | ParkingDoorsOpen        | 0   | 1     | 0       |



Via Caduti del Lavoro, 16/22

43058 Sorbolo Mezzani (PR)

**Tel. +39 0521 695311**

[info@arealifting.com](mailto:info@arealifting.com)

[www.arealifting.com](http://www.arealifting.com)

---

MADE IN ITALY

---