


# InDomo HP

## Platform lift



## MAINTENANCE INSTRUCTIONS

6.3	Update p. 7	22.02.2022
6.2	Insertion Lumiere maintenance, update spare parts list	14.06.2018
6.1	Insertion p. 9 - Maintenance in case of counter-ceiling	16.05.2018
6	General update and new layout	30.01.2013
5	Nomenclature update	26.05.2010
4	Detail revision	02.05.2010
Rev.	Description	Date

## TABLE OF CONTENTS


<b>1. GENERAL REQUIREMENTS AND INSTALLATION SITE MANAGEMENT .....</b>	<b>6</b>
1.1. GENERAL REQUIREMENTS .....	6
<b>2. PRELIMINARY CONTROLS.....</b>	<b>7</b>
2.1. PRELIMINARY SAFETY CHECKS.....	7
2.2. PRELIMINARY CHECKS OF THE INSTALLATION SITE.....	7
2.3. OBLIGATIONS OF THE INSTALLER.....	7
<b>3. TEST PROCEDURE .....</b>	<b>8</b>
3.1. GENERAL INFORMATION .....	8
<b>4. MAINTENANCE TOOLS.....</b>	<b>9</b>
4.1. OUT OF SERVICE MODE .....	10
4.2. MAINTENANCE OPERATIONS.....	10
4.3. IN FRONT OF THE CONTROL BOARD.....	10
4.4. IN THE PIT .....	11
4.5. INSIDE THE CAR .....	12
<b>5. USE OF EMERGENCY KEY .....</b>	<b>16</b>
<b>6. USE OF THE LANDING DOORS EMERGENCY KEY.....</b>	<b>23</b>
<b>7. UNBLOCKING AFTER SAFETY DEVICE INTERVENTION .....</b>	<b>23</b>
7.1. BLOCK VALVE .....	23
7.2. SAFETY BRAKE .....	23
<b>8. USE OF EMERGENCY KEY .....</b>	<b>24</b>
<b>9. SPARE PARTS LIST .....</b>	<b>24</b>
<b>10. LUMIERE FLOOR DOOR MAINTENANCE - Manual door closer .....</b>	<b>25</b>



## PURPOSE OF THE MANUAL

The purpose of this manual is to provide correct information on the installation and correct use of the product, in order to contribute to personal safety and to the proper functioning of the system. Keep the manual for the entire life of the product. In the event of a change of ownership, the manual must be provided to the new user as an integral part of the product.

### NOTICE



**READ THIS MANUAL CAREFULLY** before installing and using the product. This product must be installed and put into operation according to the provisions and regulations in force. Improper installation or improper use of the product can cause damage to people and property, as well as cause the warranty to lapse.

**FOLLOW THE SUGGESTIONS AND RECOMMENDATIONS TO OPERATE IN SAFETY.** Any unauthorised modification can compromise the safety of the system, as well as the correct operation and the life of the machine. If you have any doubts regarding the correct understanding of the information and contents contained in this manual, contact LIFTING ITALIA S.r.l. immediately.

**QUALIFIED PERSONNEL:** The product covered by this documentation can only be installed by qualified personnel, in compliance with the attached technical documentation, above all in compliance with the safety warnings and the precautions contained therein.

Keep the technical and safety documentation near the lift system.



## PERSONAL SECURITY AND RISK RECOGNITION

This manual contains safety rules that must be observed to safeguard personal safety and to prevent damage to the property. The indications to be followed to guarantee personal safety are highlighted by a triangle symbol while those to avoid material damage are not preceded by the triangle. The hazard warnings are shown as follows and indicate the different levels of risk in descending order.

### RISK SYMBOLOGY AND PHRASES

RISK CLASSIFICATION AND RELATIVE GRAVITY OF DAMAGE		
 <b>DANGER</b>	The symbol indicates that the failure to comply with appropriate safety measures <b>causes</b> death or serious physical injury.	
 <b>WARNING</b>	The symbol indicates that the failure to observe the corresponding safety measures <b>can cause</b> death or serious personal injury.	
 <b>CAUTION</b>	The symbol indicates that failure to observe the relevant safety measures <b>can cause</b> minor or moderate personal injury or damage to the device.	
<b>NOTICE</b>	It is not a symbol of security. It indicates that the failure to comply with relevant safety measures <b>can result</b> in property damage.	
<b>INFORMATION</b>	It is not a symbol of security. It indicates important information.	

If there are multiple levels of risk, the danger warning always indicates the highest one. If a warning is drawn with a triangle to warn of the risk of injury to persons, the risk of possible property damage may also be caused at the same time.

**NOTE:** During installation / maintenance of the platform, the safety functions are temporarily suspended. Therefore, all necessary precautions must be taken to avoid personal injury and / or damage to the product.



## MANUAL READING GUIDE

### WARNING SIGN

	GENERAL DANGER		ELECTRICITY DANGER		DANGER FLAMMABLE MATERIAL
	DANGER OF FALL BY A LEVEL		DANGER SUSPENDED LOADS		DANGER OF CRUSHING

### PROHIBITION SIGN

	GENERIC PROHIBITION		FORBIDDEN TO STEP ON		PROHIBITED TO WALK ON OR STOP IN THIS AREA
--	---------------------	--	----------------------	--	--

### MANDATORY SIGN

	OBLIGATORY TO WEAR THE PROTECTION HELMET		OBLIGATORY TO WEAR SAFETY SHOES		OBLIGATORY WEAR THE PROTECTIVE GLOVES
	OBLIGATORY TO WEAR EYE PROTECTION		OBLIGATION TO WEAR THE AUDIO PROTECTION		OBLIGATORY TO WEAR THE MASK
	OBLIGATORY TO WEAR PROTECTIVE CLOTHES		OBLIGATORY TO KEEP CLOSED		OBLIGATORY TO CHECK THE PROTECTIONS

### EMERGENCY AND FIRST AID SIGNS

### INDICATION SYMBOLS

	FIRST AID		NOTE WELL		KEEP DRY		OBLIGATORY TO CHECK THE PROTECTIONS
--	-----------	--	-----------	--	----------	--	-------------------------------------



## LIABILITY AND WARRANTY CONDITIONS:

### RESPONSIBILITY OF THE INSTALLER

The elevator / platform is produced and intended to be installed as described in the attached project drawing and in this manual; any divergence from the prescribed procedure may affect the operation and safety of the system and cause the immediate cancellation of the warranty.

Any modification or variation made to the project and the to the assembly Instructions must be documented in detail and referred to LIFTING ITALIA S.r.l., in order to allow the company an adequate assessment. Under no circumstances can a modified system be activated without the express authorization of LIFTING ITALIA S.r.l.

Installers are responsible for ensuring compliance with safety procedures at work and any health and safety regulations in force in the country and on the site where the assembly is carried out.

The elevator / platform must only be used in the way envisaged by the system and illustrated in the relative manuals (transportation of people and / or things, maximum loads, cycles of use, etc.). LIFTING ITALIA S.r.l. assumes no responsibility for damage to persons and property caused by improper use of the system.

**NOTE:** Pictures and images on this manual are for illustration purposes only.

## 1. GENERAL REQUIREMENTS AND INSTALLATION SITE MANAGEMENT

### 1.1. GENERAL REQUIREMENTS

#### IMPORTANT!

 For more information on safety, liability and warranty conditions, receipt and storage of material on site, packaging, waste disposal, cleaning and storage of the product; refer to the "**SAFETY INSTRUCTIONS AND SITE MANAGEMENT**" manual.

#### NOTICE

**PRELIMINARY CHECKS:** Once the packaging has been opened, check that the product is intact and has not been damaged during transport. Should any anomalies or damage be found, please dispatch them in writing on the transport document to the transport company, giving written notice to LIFTINGITALIA S.r.l.


**NOTE:** In this manual, we will talk about "SHAFT" meaning for it the base slab, the slab of landing and the vertical wall that connects its slabs.

#### CAUTION

#### SAFETY AND SITE MANAGEMENT - OVERALL DISPOSITIONS:


1. Always secure tools and any objects against falling;
2. Pay the utmost attention to all the steps described in this;
3. While assembling the parts making up the system or after installation, be careful of any sharp burrs (machining residues);

- Before proceeding with the installation, it is necessary to remove any rubble and material deposited during the construction of the shaft.
- Only nuts and bolts included in the supply must be used.
- The bags containing the screws must be opened in correspondence with the respective operating phases indicated in this manual.
- The instructions described in this manual refer to a reinforced shaft, to a fastening with mechanical expansion plugs of the stud type. For the use of plugs in masonry other than the reinforced concrete see the attachment to this manual. For the shafts with metal framework, we proceed by replacing the plugs with normal screws.
- In these instructions and on the wiring diagram, the stops are indicated with 0, 1, (2, 3 etc.), meaning "0" the lowest stop: the numbers on the push-button panels may be different according to the user's needs (for example- 1, 0, etc.).



The assembly must be performed by a **MINIMUM 2** people;

If the load is greater than 50kg, use the hoist for handling.





## 2. PRELIMINARY CONTROLS



### 2.1. PRELIMINARY SAFETY CHECKS



#### WARNING

##### BEFORE STARTING THE INSTALLATION/MAINTENANCE, YOU NEED TO:

- Check that the main electrical system is up to standard and provided with adequate grounding; **Otherwise, stop the installation until the Customer has updated the system.**
- Check the presence of an efficient lighting system at the place of installation;
- Check the cleanliness of the shaft area/pit that there are no liquids (water, oil, ...) on the bottom;
- Check that the entrances to the work areas are properly closed.
- Check that all the holes and the housings for the electric cables are free, inspectable, well finished and dry;
- Check that there is adequate ventilation for the smoke exhaust;

### 2.2. PRELIMINARY CHECKS OF THE INSTALLATION SITE

#### NOTICE

##### BEFORE STARTING THE INSTALLATION, CHECK THE FOLLOWING MEASURES AND COMPARE THEM WITH THOSE ON THE PROJECT DRAWING:

- Width (distance between the side walls)
- Depth (distance between front and back wall)
- Base/Pit depth
- Travel
- Headroom height
- Plumbing of the shaft and any plumb parts already installed
- Dimensions of any necessary arrangements (breaking down the landing doors, distance between the guides,
- Determine the finished floor level of each floor;

**Measure the width and length of the shaft at all levels. Perform the dimensional checks independently of the measurements taken by the building contractor.**

### 2.3. OBLIGATIONS OF THE INSTALLER



##### BEFORE STARTING THE INSTALLATION, YOU NEED TO:

- Arrange a material deposit area near the work area, easily accessible and protected from the bad weather.
- Prepare any lifting equipment to be used.
- Check the presence of all materials, using the list.
- Check the state of all materials at the time of receipt on site and in case of damage or missing contact the supplier immediately.
- Periodically check the materials destined for long storage before installation to avoid possible deterioration caused by incorrect storage.
- Check the completeness of the attached documentation.

### 3. TEST PROCEDURE

The platform lift has been designed to reduce the necessity of periodical maintenance. The safety components have been certified in accordance with the current regulations. The platform lift has been certified in accordance with Machine Directive 2006/42/CE, to guarantee the maximum realibility of the products and the complete user's safety. The actual maintenance requirements comprise a periodical check by an authorized Body, to be effected every two years. We recommend that maintenance operations be effected to ensure the correct functioning of the lift. The owner of the lift is invited to plan and strictly follow the maintenance operation schedule. Should any irregularity or trouble occur, the maintenance personnel must be notified immediately.

INFORMATION	
	As far as the following items are concerned : general instructions, safety instructions, responsibility and warranty, material receiving and storage on site, packing, waste disposal, cleaning and maintenance, please consult the manual " <b>SAFETY AND MATERIAL HANDLING ON SITE</b> ".

#### 3.1. GENERAL INFORMATION

The stops are indicated as 0, 1, 2, 3, "0" meaning the lowest floor: the COP numbering may be different according to the customer's needs (example -1, 0, etc.);

The other reference documents are as follows:

- Project drawings referred to the lift;
- Electrical schemes an instructions;
- Hydraulic scheme.

For threaded fixings coupling, please respect the below table.











All the screws used for the lift assembly, have been tightened using the parameters stated in the below table.

SCREW	COUPLE MAX (Nm)	COUPLE MIN (Nm)
M3	1.2	1.0
M4	2.6	2.1
M5	5.1	4.1
M6	9.0	7.0
M8	21.0	17.0
M10	42.0	34.0
M12	71.0	57.0
M16	175.0	145.0

In case of necessity, consult the table.

**4. MAINTENANCE TOOLS**
**NOTICE**

The lift maintenance operations must be carried out by qualified personnel, authorized in accordance with the current legislation.

Hammer		Tape measure		Insulation tape		Scissors for electricians	
Flat-blade screwdriver		Spanner 5 ÷ 27 mm 2 each size		Ratcheting ring spanner 13 to 19 mm		Allen key with ball end 2,5 to 8 mm	
Phillips screwdriver		Socket wrench 5 to 27 mm		Platform or foldable safety ladder, 5 steps		Digital Multimeter	
Adjustable pliers		Portable lamp		Chronometer			
Drill for Brickwork Metal		6 to 22 mm 2 to 13 mm					

#### 4.1. OUT OF SERVICE MODE

The following instructions describe the out of service procedure.

1. Make sure the car is empty;
2. Bring the car to the lowest floor;
3. Wait for the busy signal to be off;
4. Open all the circuits of the power supply board;
5. Check if all the other landing doors are closed correctly;
6. Arrange the "out of service" boards to be placed on all landings.

On completion of the above listed operations, the lift can be considered out of service, and cannot be used.

#### 4.2. MAINTENANCE OPERATIONS

The frequency and the description of the operations are stated in the table, paragraph 1.5. The recommended frequency is referred to the normal use of the lift, which means 1200 runs per month; a more frequent use requires a more frequent maintenance. The commissioning operations fare listed in the Installation Manual; these are to be repeated, should there be a time gap of more than six months between the installation and the commissioning dates, or should the service be suspended for more than six months. Should any element need to be replaced, we recommend using original components from the supplier LIFTINGITALIA S.r.l.



The operations described below are to be effected by qualified personnel only.

The following maintenance areas have been identified:

1. IN FRONT OF THE CONTROL BOARD;
2. IN THE PIT;
3. ON THE PLATFORM ("CAR").

The following table shows the maintenance areas in connection with paragraph 1.5.

<i>maintenance area</i>	<i>N. of operation</i>
In front of the control board	2, 6, 7, 10, 11, 12, 13, 14, 15, 16, 17, 19, 20, 27, 28, 30, 31
In the pit	7, 8, 9, 15, 18, 23, 24, 25, 26, 31
Inside the car	1, 2, 3, 4, 5, 7, 8, 9, 16, 21, 22, 23, 24, 25, 26, 29

Make sure that all the safety measures are taken, before starting to work in the maintenance areas.

#### 4.3. IN FRONT OF THE CONTROL BOARD





Several operations are to be effected in front of the control board under power.

- disable power by means opening the main switch;
- close the main switch only if required, paying attention to the safety rules to be followed in presence of components under power.

**4.4. IN THE PIT**


**CAUTION**
**DANGER OF CRUSHING - BEFORE ACCESSING THE PIT IT IS MANDATORY:**

- Activate the "pit safety device" (Safe-Pit) as indicated in the following instructions.
- Open the main switch located in the power supply panel (ref. IM.TEC.026 § 5.6).
- Perform the anti-entrapment procedures described in the following instructions (point 4).

**SAFE-PIT\* CLOSED (deactivated)**

**SAFE-PIT\* OPEN (activated)**


\* SAFE-PIT = PIT SAFETY DEVICE



1. Bring the car to one of the upper floors, possibly at the minimum height of 2500mm from the pit bottom and in any case OUT OF THE LANDING FLOOR (red led on the door of the control panel OFF). In this way, the Safe Pit device can be easily enabled;
2. open the landing door using the unblocking key;
3. as soon as the landing door has been unblocked, a light and sound emergency signal will be enabled, to remind the maintenance operator of the "Safe Pit" device to be activated; utilized a special lever;
4. In the event of an electric lock, release the lock bolt pushing the white button **A** by using the tip of a screwdriver and CHECK THAT BY CLOSING THE DOOR IT DOES NOT LOCK;
5. USE DEVICES TO KEEP THE LANDING DOOR OPEN;
6. Activate the "pit bottom safety device" by operating it from the outside;
7. should you have trouble when positioning the Safe Pit device, and should the light and sound signal still be on, it means that the car is too close to the pit bottom. So, close the landing door, reset the control board and send the car to the upper floor. Get back to the previous sequence of steps;
8. as soon as the light and sound signal is deactivated, pit access and maintenance operations inside are possible;
9. upon the work completed, leave the pit and close the Safe Pit. The light and sound signal will be active again until the device has returned to the resting position. Close the landing door and check it is locked off correctly.
10. Make sure all the landing doors are closed and locked off.
11. Reset the control board in order to put the lift into operation.



**4.5. INSIDE THE CAR**
**WORKING ON THE BACK SIDE OF THE CONTROL BOARD**

The Platform lift has been designed to guarantee an easy access to the safety brake directly from the car. Follow the below instructions:

- with the car stationary at one of the stops, open the Mains Supply Switch, press the STOP button in car and make sure that the lift cannot be commanded from the control board;
- remove the service panel unscrewing the safety screws;

**Hull height COP****Half height COP**

- put the service panel aside;



Make sure the wires are not pulled during the panel removal.


- effect the necessary operations on the safety brakes;
- re-position the service panel and fix it with the safety screws;
- unblock the STOP button in the car, close the Mains Supply Switch and check the correct functioning of the lift.

### ACCESSING THE UPPER PART OF THE LIFT

The Platform Lift has been designed in order to avoid maintenance operations on the car roof that is normally not bearing: all the sensors are fixed above the frame, so that the operator can access easy them, by leaning over the car ceiling while working inside the car. The same thing concerns magnets and overrun switch positioning in the shaft. Should the maintenance require accesing components located on the roof, follow the below instructions:


- press the STOP button in the car and make sure that the lift cannot be commanded from the control board; the STOP must be enabled every time the safety mode is to be activated;
- disable the STOP button and bring the car to the height of 300mm under the upper landing level. In case of doorless car, it is an easy operation, while in presence of car doors, different attempts must be made, using COP buttons and remaining inside the car;
- in the required position, press the STOP button in the car and make sure that the lift does not move. Remove the roof lid unscrewing the two safety screws, and then pushing the away from the COP side. Now, a sound signal will warn that the headroom spacer must be enabled;

### MAINTENANCE IN CASE OF COUNTER-CEILING




**CABIN ROOF ACCESS**

**1-piece ceiling**




**3-piece ceiling**





The car roof is not bearing. Do not step on the roof, or on the rims.

- put the headroom spacer in vertical position. The acoustic signal will be disabled, which means that the maintenance in the headroom is possible;



- lean over the roof, using a safety ladder or platform, and effect the necessary maintenance operations;




Do not step on the roof. It is not bearing.

- to move the car during the maintenance operations, return inside the car completely, bring the headroom spacer to the resting position, close the safety lid completely and unblock the STOP button in the car;



- Do not force any operation with the operator leaning over the car roof, descent included.
- Do not force any operation with the safety lid up – risk of collision (with shaft elements) exists.

- on maintenance completed, return inside the car completely, bring the headroom spacer to the resting position, close the safety lid completely and unblock the STOP button in the car; then check the correct functioning of the lift.



## 5. USE OF EMERGENCY KEY

OPERATION	RECOMMENDED FREQUENCY			
	1st run	every 6 months	every 1/2 year(s)	every 5/10 years
<b>CAR MOVEMENT AND FLOOR LEVELLING</b>  Check the correct car movement and stops using the related commands.  from the car: try to send the lift to each of the stops (both during ascent and descent), checking the correct automatic stop, with the maximum difference in height of 10 mm above or under the landing level; in absence of car doors: the lift must stop immediately when the car button is released; inside the levelling zone the lift will stop at the landing level; from all the landings: try to call the lift, checking the correct automatic stop and the "busy" and "present" lights functioning; make sure that the lift cannot be commanded from the COP without the enabling key.	•	•		
<b>EMERGENCY POWER SUPPLY</b>  Check the efficiency of the emergency power supply unit, as far as alarm, car emergency lighting and forced descent to the lowest floor are concerned.  bring the car to the upper floor; switch the power off by opening the power supply switch (not the Driving Force one) located on the power supply board; car emergency light will be enabled; push the alarm button: the siren will be activated; press and hold any call button: the car will descend and stop at the lowest stop level, then the door can be opened (sliding doors open automatically).  For battery replacement (batteries inside the control board) follow the below instructions.  open the Driving Force Switch and enable the control board lighting; disconnect the battey connectors, trying to avoit shorts; replace batteries and re-connect the connectors; close the Driving Force Switch, disable the control board lighting and repeat test operations from A. to E.; dispose of the exhausted batteries bringing them to the authorized points (as special and dangerous waste).	•	•		

OPERATION	RECOMMENDED FREQUENCY			
	1st run	every 6 months	every 1/2 year(s)	every 5/10 years
<b>PHOTOCELLS OR LIGHT BARRIERS (if any)</b>  Check the efficiency of all the photocells or light barriers.  WITHOUT car doors: remain in car and command the ascent; outside the floor levelling zone, intercept the photocell area; the lift will stop until the obstacle has been removed and the ascent has been newly commanded; repeat with each photocell; repeat inside the floor levelling zone.  WITH car doors: Intercept the barrier area during the automatic closure; the door will re-open.	•	•		
<b>LOCKS</b>  Check the locks of all the landing doors.  Check the correct opening-closing movement, with and without the emergency key; Check if the removable bridge on the fixed contact, as well as the lock chain in the doorleaf hole have been assembled properly; Check the independence between the chain contact and the preliminary half-closing contact.	•	•		
<b>PISTON SYNCHRONISM</b>  Check if the two stems arrive to the end-of-run simultaneously (car in lower overrun).	•	•		
<b>MAUAL PUMP - EMERGENCY DESCENT BUTTON</b>  Check the efficiency of emergency ascent and descent devices.  open the Driving Force main switch located on the power supply board; with the car stationary at the lowest stop, activate the manual pump for some ten cycles; open the door with the emergency key and check the car lifting; close the door press and hold the red "Emergency descent" button; check if the descent has taken place.	•	•		
<b>PISTON SEALS TEST</b>  Check the oil quantity in the recovery bottle (500 ml): it does not have to be filled for two further tests.	•	•		

OPERATION	RECOMMENDED FREQUENCY			
	1st run	every 6 months	every 1/2 year(s)	every 5/10 years
<b>GUIDE RAIL SHOES</b>  The play of the shoes must be 1-2 mm. Major gaps can be made up for, by means of shoe bearers adjustment; orthogonal gaps require shoe replacement.	•	•		
<b>GUIDE RAILS</b>  The guide rails must be lubricated by a mix of oil (grade $\geq$ 220 cst, EP-free) and grease (50-50). The lowest piece must be lubricated from the pit.	•	•		
<b>OIL LEVEL</b>  Let the air escape from the cylinder. Check if the oil level in the cylinder is above the minimum (or covers the pump completely) when the car is stationary at the upper stop.  For topping up, use ISO VG 46 oils.	•		• 1	
<b>Oil filter (if present)</b>  Check the oil injection filter of the pump and clean it, if necessary.	•		• 1	
<b>VALVE HYDRAULIC SEAL</b> (eseguire la prova con olio a temperatura ambiente).  open the throttle of the pressure gauge, close the injection valve and switch the power off by opening the Driving Force main switch located on the power supply board; use the manual pump to bring the dispenser to the nominal pressure; wait for 5 minutes and check for possible pressure drops; open the valve, close the throttle of the pressure gauge and switch the power on.	•		• 1	
<b>OVERPRESSURE VALVE</b>  Check if the intervention pressure does not exceed the standard value (1.4 the maximum static pressure). close the injection valve and open the throttle of the pressure gauge; command the ascent (ex. from an upper floor); read the maximum pressure value on the gauge (must be $\leq$ 63 bar); open the injection valve and close the throttle of the pressure gauge.	•		• 1	

OPERATION	RECOMMENDED FREQUENCY			
	1st run	every 6 months	every 1/2 year(s)	every 5/10 years
<b>BLOCK VALVE</b>  Check the block valve activation with the car fully loaded and stationary at the upper landing level.  switch the power by opening the Driving Force main switch located on the power supply board; remove the calibration from the downspeed adjustment screw (as described in the manual of the hydraulic unit); press and hold the red "Discesa di emergenza" emergency descent button and the central pin of the EVD valve; the car will stop; restore the calibration of the downspeed adjustment screw (as described in the manual of the hydraulic unit).	•		• 1	
<b>OIL PIPING SEAL</b>  Check for possible oil leakage from different components: hose break valve, hydraulic unit, joints, pipes etc. Verify the good condition of the hose and the related joints.	•		• 1	
<b>UPPER OVERRUN</b>  Check the safety contact.  send the empty car to the upper floor; command the ascent, using the manual pump, until the activation of the overrun contact (make several attempts: the contact is activated when the lift does not react to calls).	•		• 1	
<b>GROUNDING</b>  Verify the efficiency of the grounding and the electrical circuit insulation, as described in the electrical scheme.	•		• 1	
<b>LIGHTING</b>  Check the correct functioning of the lighting systems: in the car, in the shaft (if foreseen) and in the control cabinet.	•		• 1	
<b>OIL FEATURES</b>  Make sure that the oil has preserved the original features. Every two years, pick up some oil from the tank, to check its clearness; replace completely, if needed			• 1	

OPERATION	RECOMMENDED FREQUENCY			
	1st run	every 6 months	every 1/2 year(s)	every 5/10 years
<b>MAXIMUM STATIC PRESSURE WITH FULL LOAD</b>  Make sure that the working pressure has not been changed (fully loaded car).  bring the car to an upper stop; open the throttle of the pressure gauge; read the indicated value; close the throttle of the pressure gauge.	•		• 2	
<b>OVERLOAD</b>  Make sure the operation mode with overloaded car is disabled. load the car; bring the car to the first stop; open the landing door and enter the car; close the door; make sure that the lift does not react to the inner not outer commands.	•		• 2	
<b>PULLEYS</b>  Effect a complete run and make sure that the pulleys rotate onto the pins.	•		• 2	
<b>SUSPENSION ROPES</b>  Inspect the ropes and the related joints, to detect the presence of broken, worn out or oxidised elements. verify if the rope clamps are well closed, both on the side of the car and on the side of the shaft; check the uniform tension of the two ropes; Inspect the ropes, to detect the presence of broken, worn out or oxidised wires. Maximum 10 broken wires are acceptable on a 70mm's rope length ; the section may be reduced by 2 mm <sup>2</sup> maximum due to wear or abrasion (even in absence of broken wires); corrosion or oxidation on ropes and joints are NOT acceptable.	•		• 2	

OPERATION	RECOMMENDED FREQUENCY			
	1st run	every 6 months	every 1/2 year(s)	every 5/10 years
<b>2:1</b> <b>SAFETY BRAKE DEVICE</b>  Verify the correct functioning (empty car). check the synchronizing leverism of the two brakes; prepare the rope slackening device for use, by removing the screws; test procedure: one operator works by the control board, another one - at the lowest stop; bring the car to 1 m height from the pit bottom; command the descent by means of the red emergency button; pull the rope to activate the rope slackening device; continue the descent, so eventually the ropes are slackened with the related springs, and the car is suspended on brakes only; make sure the yoke has not been lowered due to the absence of weight; command the ascent of the lift: the car must remain idle; restore the ropes tension, using the manual pump, then continue the ascent to unblock the brakes; check the correct position of the ropes and all the mobile parts, then reset the safety brake contact using the control board; command the ascent electrically: the start must be regular; bring the car to the 2.5m distance from the pit bottom; enter the pit (enable the SafePit device beforehand) and reload the rope slackening device ; check the two imprints left on the guide rail, the imprints must have the same length ( $\pm 10$ mm) and be located at the same height ( $\pm 20$ mm); restore the lift operation mode.	•	• 2		
<b>ELECTRICAL WIRING</b>  Check the integrity of the lines, either fixed and mobile.	•	• 2		
<b>SHAFT CONTACTS</b>  Check the integrity of the following contacts: doorlock block exclusion and floor levelling .	•	• 2		
<b>CONTACTORS</b>  Check the contactors and their integrity.	•	• 2		

OPERATION	RECOMMENDED FREQUENCY			
	1st run	every 6 months	every 1/2 year(s)	every 5/10 years
<b>PLATES - SCHEMES</b>  Verify the presence of the followings schemes and plates:  pit plate (danger in case of access, safety devices required); car roof plate (not bearing surface); control board plate (electrical hazard, access forbidden); control board plate (beside the board, emergency procedure); red emergency button identification plate; landing door plate (use reserved to less able people, for public places only); car plate (load, capacity, constructor's name, emergency descent procedure in case of power blackout); electrical and hydraulic schemes inside control board (or machine room).	•		• 2	
<b>SPEED - PICKUP - SLOWING DOWN</b>  Make sure the actual parameters match the set values.	•		• 2	
<b>TOTAL HYDRAULIC INSPECTION</b>  The hydraulic components must be totally inspected to restore the conditions altered due to oil contamination and ageing. The procedure is as follows:  filter the oil and clean the tank (using 30 - 40 micron filters); disassemble the top of the cylinder and the distribution head; check all the seals and replace them if needed; check and clean the filters; reassemble the components and check the fine tuning as if it were a new installation.				• 5
<b>HOSE REPLACEMENT</b>  Replace the hose every 10 years.				• 10

## 6. USE OF THE LANDING DOORS EMERGENCY KEY



Opening doors by means of the triangular emergency key may be dangerous. Be extremely careful.



A difference of height exceeding 30 cm between the car floor and the landing level, may imply a serious risk of falling inside the shaft. Therefore, **NEVER use the intermediate landing door during rescue operations.**

To unblock and open the landing door, first open the driving force main switch, then insert the safety key in the special hole in the jamb, then turn the key. Open the door carefully, making sure of the car position in respect to the landing. Upon the operation completed, make sure that all the landing doors are locked and blocked.



The car roof is NOT BEARING. Do not step on the roof nor on its edges.

## 7. UNBLOCKING AFTER SAFETY DEVICE INTERVENTION



### 7.1. BLOCK VALVE

Should the block valve be activated, follow the below sequence of steps to unblock the lift.  
 check the presence of passengers in car, and their health condition;  
 reassure the passengers and explain the next steps you will take;  
 go to the machine room, open the Driving Force switch and position yourself in front of the hydraulic unit, then identify the manual pump bearing the plate "CAUTION - EMERGENCY ASCENT";  
 act on the pump and lift the car by some centimeters, in order to unblock the valve;  
 should there be any passengers inside, effect an emergency descent manually, pressing the red button bearing the plate "CAUTION - EMERGENCY DESCENT" until the car comes to a stop and the passengers can get out normally;  
 put the lift out of service.

2:1

### 7.2. SAFETY BRAKE

Should the safety brake be activated, follow the below steps to unblock the lift.  
 check the presence of passengers in car, and their health condition;  
 reassure the passengers and explain the next steps you will take;  
 go to the machine room, open the Driving Force switch and position yourself in front of the hydraulic unit, then identify the manual pump bearing the plate "CAUTION - EMERGENCY ASCENT";  
 act on the pump and lift the car by some centimeters, in order to unblock the safety brake;  
 should there be any passengers inside, effect an emergency descent manually, pressing the red button bearing the plate "CAUTION - EMERGENCY DESCENT" until the car comes to a stop and the passengers can get out normally;  
 put the lift out of service.

## 8. USE OF EMERGENCY KEY

	<b>ATTENZIONE</b>
	Usually a damaged frame (especially if the damage was caused by a bending, excessive heat etc.) cannot be replaced. The damaged parts must be replaced. Only spare parts by LIFTINGITALIA S.r.l. can be used for replacement.
	The repair operations must be carried out by qualified personnel, with the maximum care, to guarantee post repair efficiency.

The following operations can be carried out directly in place by qualified personnel:

- Sanding down the rust (caused by painting faults) and anti-rust layer application;
- Shoes (or parts of shoes) replacement;
- Rope replacement.

## 9. SPARE PARTS LIST


Component	Description	Q.ty	Code
Roller shoes	Roller Ø56	4	F600.05.9096
	Roller Ø78	4	F300.04.0014
Sliding shoes	Lateral shoes	4	F300.05.0002
	Yoke shoe seals	2	F600.05.9057V04
Safety brake	Safety brake	1 couple	Plate number is required
Rope	Suspension rope	2	Plate number is required

10. LUMIERE FLOOR DOOR MAINTENANCE - Manual door closer



INFORMATION



**ADJUSTING THE CLOSING SPEED AND THE FORCE OF THE FINAL STROKE**, which are usually performed using special screws, **ARE IMPORTANT**, both to adapt perfectly the action of the door-closer to the weight of the door on which it is applied, and to ensure effective operation in all seasons. The viscosity of the internal oil actually changes in relation to the external temperature. **THE ACTION OF THE DOOR-CLOSER IS THEREFORE SUBJECT TO NATURAL SEASONAL VARIATIONS THAT MAY REQUIRE MINOR PERIODIC ADJUSTMENTS**, in order to maintain the effectiveness of the mechanism. The door-closer has 2 different adjustments: the closing speed and the force of the end stroke that is used to overcome the lock latch resistance at the time of closing.



Adjust the force of the end stroke and then the Acceleration Speed according to the weight of the door by rotating screw A no greater than 30°÷45°.  
Adjust and periodically check the Closing Speed by rotating screw B no greater than 30°÷45°.





LIFTINGITALIA®

COMFORTABLE  
HOMELIFTS